

Philips
Component DVD micro
system

100W
subwoofer

MCD183



Obsessed with sound

Relax with great music and movies

Be assured of cinematic room-filling sound with the Philips component DVD micro system. The speaker system backed with 100W RMS total output power allows you to feel every sound effect. Also features USB Direct for photo and music playback.

Enrich your movie experience

- Play DVD, DivX®, (S)VCD, MP3-CD, WMA-CD, CD(RW) & Picture CD
- Dolby Digital for ultimate movie experience
- Progressive Scan component video for optimized image quality

Enrich your sound experience

- USB Direct for music and photo playback
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- Total 100W RMS

Start the day your way

- Wake up and sleep timer functions
- Digital tuning with 20 preset stations for extra convenience

PHILIPS

Highlights

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume

settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

USB Direct

Simply plug in your USB device on the system and share your stored digital music and photos with your family and friends.

Play DVD, DivX & MP3/WMA-CD

The Philips player is compatible with most DVD and CD discs available in the market.

DVD, DivX®, (S)VCD, MP3/WMA-CD, CD(RW) and Picture CD - all of them can play on the player. SVCD stands for "Super VideoCD". The quality of a SVCD is much better than a VCD, especially much more sharpen picture than a VCD because of the higher resolution. With DivX® support, you are able to enjoy DivX® encoded videos. The DivX media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, and DVD recordable discs.



Specifications

Sound

- Output power: 100 W RMS, 2 x 25 W + 50 W RMS / 1800 W PMPO
- Sound enhancement: digital sound control 4 modes, Dynamic Bass Boost, Dolby Digital

Loudspeakers

- Speaker drivers: 3" woofer
- Subwoofer types: passive

Video Playback

- DVD region code: 2
- Playback media: DVD+RW, DVD-Video, picture CD, video CD/SVCD, DivX, DVD, DivX Ultra
- Disc playback modes: angle, PBC, slow motion, Zoom, OSD, resume playback from stop, parental control, A-B Repeat
- Video enhancement: progressive scan

Audio playback

- Playback media: WMA-CD, MP3-CD, CD, CD-R, CD-RW
- Disc playback modes: repeat/shuffle/program
- USB Direct playback modes: fast backward/fast forward, play/pause, previous/next, repeat, shuffle, stop

Tuner/Reception/Transmission

- Tuner bands: FM stereo
- Station presets: 20
- Antenna: FM antenna
- Tuner enhancement: auto digital tuning, auto scan

Connectivity

- Audio/Video output: 2xRCA (Audio), component video out, composite video (CVBS) out, SCART

- out, S-Video out
- Aux in: 2xRCA (Audio)
- MP3 Link: 3.5mm stereo line in
- USB: USB host

Convenience

- Alarms: CD alarm, radio alarm
- Number of discs: 1
- Clock: on main display, sleep timer
- Loader type: tray
- Display type: LCD display

Accessories

- Cables/Connection: composite video cable (Y), MP3 Link cable, power cord
- Remote control: 38-key with lithium battery
- Others: FM antenna, Quick start guide, User Manual
- Warranty: World Wide Guarantee booklet

Dimensions

- Gross weight: 8.5 kg
- Main speaker dimensions (W x D): 135 x 150 mm
- Main speaker height: 255 mm
- Main unit depth: 270 mm
- Packaging depth: 350 mm
- Main unit height: 125 mm
- Packaging height: 314 mm
- Main unit width: 200 mm
- Packaging width: 545 mm
- Subwoofer depth: 250 mm
- Subwoofer height: 255 mm
- Subwoofer width: 160 mm

Power

- Power supply: 220 - 240 V



Issue date 2014-02-07

Version: 2.0.7

12 NC: 8670 000 50834
EAN: 87 12581 47260 3

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com