



Philips  
Micro music system

CD, MP3-CD, USB, FM  
20W

MCM2000

## Relax to great music

with this compact sound system

Listen to all your favorites on your portable music player with USB Direct and MP3 Link. This Philips MCM2000/12 Micro sound system also plays MP3-CD, WMA-CD and CD-R/RW, and features Bass Reflex speakers for powerful and dramatic bass.

### Enrich your sound experience

- Bass Reflex Speaker System delivers a powerful, deeper bass
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 20W RMS total output power

### Enjoy your music from multiple sources

- Play MP3/WMA-CD, CD and CD-RW
- USB Direct for MP3/WMA music playback
- MP3 Link for portable music playback

### Easy to use

- Motorized CD loader for convenience access
- Digital tuning with preset stations for extra convenience
- Radio Data System for station information and data services

# PHILIPS

# Highlights

## Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

## Digital Sound Control



Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen

music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

## Dynamic Bass Boost



Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

## USB Direct



With the USB Direct mode, simply plug in your USB device to the USB port on your Philips device and your digital music will be played directly from the Philips device.

## MP3 Link



The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.

## Radio Data System (RDS)

The Radio Data System (RDS) lets you tune into radio stations without having to remember the frequencies. In standard mode, RDS displays the station name instead of the transmission frequency, facilitating quick and easy tuning. RDS also allows stations to send text messages such as news and station information directly to the radio display. Commonly used in Europe, RDS text is sent out on the same frequency the radio station broadcasts on. You can choose either the basic RDS display (station name) or subscribe to additional text-based services.



# Specifications

## Sound

- Output power: 2 x 10 W RMS
- Sound enhancement: digital sound control, Dynamic Bass Boost

## Loudspeakers

- Speaker drivers: 4" woofer
- Speaker types: bass reflex speaker system

## Audio playback

- Disc playback modes: fast forward/backward, next/previous track search, repeat/shuffle/program
- Playback media: CD, CD-R/RW, MP3-CD, USB flash drive, WMA-CD
- USB Direct playback modes: fast backward/fast forward, play/pause, previous/next, repeat, shuffle, stop
- Others: ID3-tag support

## Tuner/Reception/Transmission

- Tuner bands: FM mono, FM stereo
- Station presets: 20
- RDS: program type, radio text, RDS clock set, station name
- Antenna: FM antenna (75 ohm)
- Tuner enhancement: auto digital tuning, auto scan, Easy set (plug & play)

## Connectivity

- Headphone: 3.5 mm

- MP3 Link: 3.5mm stereo line in
- USB: USB host

## Convenience

- Alarms: CD Alarm, Radio Alarm, USB alarm
- Clock: On main display, sleep timer
- Display type: LCD display
- Loader type: tray

## Accessories

- Included accessories: AC Power Cord, FM antenna, Quick Use Guide
- Remote control: 31-key remote
- User Manual: 16 languages

## Dimensions

- Main unit width: 200 mm
- Main unit height: 118 mm
- Main unit depth: 210 mm
- Main speaker dimensions (W x D): 140 x 144 mm
- Main speaker height: 224 mm
- Packaging width: 576 mm
- Packaging height: 274 mm
- Packaging depth: 190 mm
- Gross weight: 3.8 kg
- Net weight: 3.24 kg

## Power

- Power supply: 220-240V, 50Hz



Issue date 2014-07-18

Version: 3.1.15

12 NC: 8670 000 78231  
EAN: 87 12581 60778 4

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)