



Wireless hi-fi headphones

- 40mm drivers/closed-back
- Over-ear
- Soft ear cushions

SHC8535/10

Wireless freedom, clear sound

Freedom to enjoy music at home. With the HiFi sound reproduction, this Philips SHC8535/10 stereo headphone is the ultimate in personal convenience.

Benefits

[You'll forget you're wearing them!](#)

- 3-way adjustment for a better fit and bass performance
- Preformed soft ear-cushions ensure a comfortable fit

[The perfect wireless listening experience](#)

- The whole ear is covered to optimize sound quality
- 40mm speaker driver delivers sound without distortion

- Convenient automatic tuning ensures best reception

[Always ready to go](#)

- FM Wireless transmission for freedom of movement
- Simple, convenient charging with a wireless dock

Features

3-way adjustable ear shells

Enjoy a comfortable fit and experience better bass performance thanks to the three-way adjustable ear shells that fit naturally around your ears.

Full size design

Full-size earshells of these Philips headphones not only cover your whole ear for better sound quality, but also provide space for a larger, higher performance driver.

40 mm speaker driver

The 40 mm speaker driver is made of a composite mylar material for a highly sensitive yet powerful element that delivers sound without audible distortion.

FM Wireless transmission

With high frequency FM wireless transmission, which can even pass through walls, you can even listen to your music when you're in another room.

PHILIPS

Convenient automatic tuning

Simple, convenient charging

Preformed soft ear-cushions

Specifications

[field not found 'disclaimer_text']

Sound

Acoustic system	closed
Magnet type	Neodymium
Sensitivity	100 dB
Speaker diameter	40 mm
Signal/noise ratio	> 68 dB
Channel separation	> 30 dB
Frequency range	10 - 21,000 Hz

Height	32.5 cm
Length	39 cm
Nett weight	1.968 kg
Tare weight	1.752 kg
Width	26 cm
GTIN	1 69 23410 71050 9
Number of consumer packagings	3

Tuner/Reception/Transmission

Pilot tone frequency	19 kHz
Effective range	100 m
Modulation	FM
Number of channel	3
Carrier frequency range	863.5 - 864.5 MHz

Packaging dimensions

Depth	12.2 cm
Gross weight	1.032 kg
Height	32 cm
Nett weight	0.656 kg
Tare weight	0.376 kg
Width	24 cm
EAN	69 23410 71050 2
Number of products included	1
Packaging type	Carton
Type of shelf placement	Both

Convenience

Battery charging indicator	yes
Automatic power off	yes
Operating time	+/- 15 hours
Low battery indicator	yes

Product dimensions

Depth	10 cm
Height	20 cm
Weight	0.308 kg
Width	19.5 cm

Power

Power supply headphone	2.4 VDC
Power supply transmitter	AC/DC adapter 8 V/375 mA

Outer Carton

Gross weight	3.72 kg
--------------	---------



data subject to change
2018, January 1

Version: 5.3.7
EAN: 6923410710502

© 2018 Koninklijke Philips N.V.
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com