

Philips
Docking Entertainment
System



DCB146



Enjoy iPod music in Hi-Fi sound

Play and charge your iPod

Experience your iPod music in superb sound quality with the DCB146. Just dock your iPod and enjoy music the way you like it. Enjoy superb clarity with built-in DAB tuner with this Micro system.

Enjoy your music from multiple sources

- Play and charge your iPod
- Play CD, CD-R and CD-RW

Enrich your sound experience

- Dynamic Bass Boost for deep and dramatic sound
- 2 x 2 W RMS total output power

Easy to use

- Wake-Up and Sleep Timer
- Digital tuning with 20 pre-set stations for extra convenience

PHILIPS

Specifications

Audio Playback

- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Fast Forward/Reverse, Next/Previous Track Search, Repeat Play, Shuffle Play
- Loader Type: Top
- Cradle playback mode: Charging iPod, Fast forward and reverse, Next and Previous track, Play and Pause

Sound

- Output Power: 2 x 2 W RMS/2 x 4 W music power
- Volume Control: Volume Control up/down
- Sound Enhancement: Dynamic Bass Boost
- Sound System: Stereo

Loudspeakers

- Main Speaker: 3" woofer

Tuner/reception/transmission

- Tuner Bands: FM Stereo, MW
- Auto digital tuning
- Station presets: 20
- DAB: Band III, Info display, Menu, Smart Scan
- RDS: Programme Type, Radio Text, Station Name

Connectivity

- Headphones: 3.5 mm
- Other connections: Fixed FM & DAB T-shape antenna, MW Antenna
- Audio Connections: 3.5mm Line in

Convenience

- Alarms: Sleep timer, Radio Alarm, CD Alarm
- Clock: On main display
- Display Type: LCD
- Backlight colour: Blue
- Backlight

Accessories

- Included Accessories: FM/MW Antenna, Remote Control, World Wide Warranty leaflet, DAB antenna
- Remote control: 24-key remote control
- Cradle: Cradle and adapters for GoGear and iPod
- User manual: English
- Quick start guide: English

Dimensions

- Set dimensions (W x H x D): 148 x 233 x 216 mm
- Main speaker dimensions (W x H x D): 134 x 230 x 152 mm
- Packaging dimensions (W x H x D): 326 x 270 x 370 mm
- Weight incl. Packaging: 4.75 kg

Power

- Power supply: 220-240 V, 50 Hz

iPod compatibility

- Compatible with: iPod, iPod mini, iPod nano, iPod with colour display, iPod 5th Generation

Highlights

Play and charge your iPod

Play and charge your iPod

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Issue date 2013-05-10

Version: 1.0.3

12 NC: 8670 000 41432
EAN: 87 12581 43600 1

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com