

Philips  
Cordless phone answer  
machine



TU5354

# Pure and simple communication

Combining comfort and efficiency

With its slim line design and its wide range of functions, the Onis 300 is both classic and sophisticated and is the perfect phone that answers your everyday need.

## **Quick & easy SMS**

- Text messaging (SMS) for short messages over a fixed line
- Eatoni predictive text entry simplifies writing SMS messages
- Display for numbers, letters, icons and drawings

## **Our phone, my style**

- Create several SMS mail boxes that can be PIN-code protected

## **Benefit from easy-to-use technology**

- Pilot key & carousel menu navigates in a menu-in-cycle form
- Identify your friends by the ringtone
- Screen incoming call and mute the ringer for more control
- Answering machine control from base and handset

## **Multi-pack for ultimate convenience**

- Use 2 handsets in separate rooms to transmit noises
- Conference call shares a conversation on several handsets
- Free intercom - Free internal calls between handsets

# PHILIPS

# Highlights

## Text messaging (SMS)

The Short Message Service (SMS) is a mechanism for delivery of short messages which can have up to 160 characters of text. These 160 characters are plain text in nature and can be comprised of words, numbers or an alphanumeric combination. The Eatoni@LetterWise predictive text editor helps you to write text messages more quickly. With its unique SMS system you can receive up to 200 messages in 10 different mailboxes. Greeting to a loved one, a quick reminder about an important meeting, ...all this can now be put in a SMS and sent over the fixed network.

## Eatoni text editor

Eatoni's LetterWise is an easy-to-use text-entry solution requiring just 1.16 taps per correct letter. It makes typing on phone keypads as comfortable, fast, and accurate as using a typewriter keyboard. It is unique among predictive text entry solutions in its ability to easily handle the entry of abbreviations, names, addresses, and URLs.

## Full graphic display

This type of displays makes it easier to use your phone, thanks to the good quality and legibility of the characters. It also gives you more freedom in communication from your home. Now you can combine text with images or numbers, when sending an SMS for example.

## Personal mail boxes

Children at a certain age need some privacy at home when sending SMS to their friends. But

paying for several mobile phones quickly gets very expensive. DECT phones provide up to 9 personal SMS mail boxes which can be protected by a PIN code - SMS can stay private despite collective phone usage. The user must tell his correspondents his mail box number so that they can send short messages directly to this personal mail box. Sending a SMS from a personal mailbox makes it easy for the addressee to reply directly to this mailbox without having to remember the mailbox number.

## Pilot key & carousel menu

The pilot key navigation system allows easy navigation and settings. The pilot key is a roller on the left side of the phone that can be scrolled up and down and pressed in the middle. It commands the Carousel menu which is a circular loop of menu icons displayed on the screen.

## VIP function

Identify who's calling by the ringtone! The VIP icons and melodies indicate to which group in the phonebook the caller belongs. Phonebook entries can be divided in different VIP groups for which you can allocate a specific ringtone.

## Do-not-disturb function

Tired of your children's friends calling just when you're about to serve dinner? The "Do-not-Disturb" function lets you screen unwanted calls and mute the ringer when you do not wish to be disturbed, but keeps the line open to the family.

## Base and handset TAM control

Just look at the base station to know instantly whether you received messages. Listening or deleting messages then become as simple as pressing one key on the base station - for those who never remember where they left their handset.

## Baby-sit function

Worried about your baby not sleeping? No need to constantly go and check in his bedroom. The baby-sit mode allows you to keep an ear on him wherever you are in the house.

## Conference call function

Thanks to the conference call, there is no need to travel to meet people. Especially useful in a professional environment where several work stations are connected to the same base station, the conference call allows, for example, two colleagues from Paris to communicate with a colleague in China. A conference call allows two handsets to share the same external phone conversation in such a manner that each handset is able to communicate with the two others.

## Free intercom

No need to stop what you are doing and go to give the handset to your son when his friend calls: you can freely and easily call the handset in his bedroom and transfer the call.

# Specifications

## Picture/Display

- Diagonal screen size - tele: 3.6 cm
- Display screen type: LCD full graphic FSTN
- Effective viewing area: 32 x 20
- Lines of text: 4

## Sound

- Base station ringers: Instrumental, Recordable melody
- Handset ringers: Instrumental
- Volume Control: digital

## Convenience

- Auto out of range warning
- Base Station keys: Answering machine keys, Paging key
- Battery charging indication
- Battery full indication
- Battery low indication
- Call Management: Call Cost, Call Forwarding, Call on Hold, Call Waiting, Caller ID, Conference Call, Explicit Call Transfer, Microphone mute, Missed Calls, Received Calls
- Carousel Icons: Phonebook, Answerphone, SMS, Intercom, Network, Extra, Base, Handset, Call log
- Drop proof: 120 cm
- Ease of Use: Hands free mode, Hot Keys, Keypad Lock
- Function: Do not disturb ringer mute, Cheapest rate function, Call cost, Alarm clock, Babysit function, Microphone mute, Conference call, Chain dialling, Direct to Do Not Disturb mode, Short cut keys, Keypad lock, Free handset to handset call
- Handset Keys: Line, Pilot key, Cancel / Recall, Dialling keypad, Loudspeaker, Call log, Phonebook
- Lines of text: 4
- Multi base capability: Up to 4 bases
- Multi handset capability: Up to 8 handsets
- Power on indication
- Text input: Eatoni
- VIP group with own melody: Yes, 3 groups
- Volume control
- Hard Icons: Answerphone message, Battery level, In range / Out of range, Line / Internal call, Loudspeaker, Not locked, Silence, SMS

## Accessories

- AC/DC Adaptor
- AC/DC Adaptor/Charger
- Batteries: 2 x AAA
- Belt clip: Belt clip on parent unit
- Cables: RJ 11 cable
- Charger: yes, 3 chargers
- User Manual

## Related Products

- Package contents: Handset, Base, 2 AAA NiMh Batteries, Belt clip, Telecom Line Cord, Power adapter, User Manual, Warranty leaflet

## Green Specifications

- Chemical composition: Nickel-Metal Hydride
- Eco Designed
- Halogen-free housing
- Packaging material: Carton
- Packaging type: Giftbox
- PVC-free product and cables
- User manual: Recycled paper

## Dimensions

- Antenna: Integrated
- Base dimensions: 149x143x57
- Base weight: 212
- Form Factor: Semi lying on base station
- Handset color: steel
- Handset dimensions: 141x40x30
- Handset weight: 212
- Packaging dimensions (W x H x D): tbc x tbc x tbc mm
- Relative humidity (operation): up to 95% at 40°C
- Relative humidity (storage): up to 95% at 40°C
- Temperature range (operation): 0°C to 40°C
- Temperature range (storage): -25°C to 70°C

## Power

- Ambient temperature: 5 °C to 40 °C
- Battery Type: NiMH
- Charging time: 12 hours hr
- Kind of Battery: Rechargeable
- Number of batteries: 2
- Power supply base station: 230V
- Radio RF power: <250mW
- Standby time: up to 250 hours
- Talk time: up to 18 hours

## Network Features

- Antenna: Fast Selection Technology
- Compatible: GAP, PABX
- Dialing: Tone, Pulse
- Messaging: Quick SMS

## Operator Requirements

- SMS
- Name and Caller ID
- Caller ID on call waiting
- Operators services phonebook

## Answering Machine

- Plug & Play Answering machine
- Recording time capacity: up to 20 min
- VIP outgoing message
- Call screening
- Answerphone remote access

## Memory Capacity

- Name & number shared phonebook: 100
- SMS storage capacity: 50
- Call log entries: 30



Issue date 2014-02-07

Version: 1.0.2

12 NC: 9961 400 01656  
EAN: 87 10895 80222 2

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)