

Philips
docking speaker



DS7700



Designed to go places

with this docking speaker

Compact and ultra-portable, this Fidelio DS7700/10 docking speaker is no lightweight when it comes to performance. Designed to travel, it delivers surprisingly powerful sound from your iPod/iPhone - letting you enjoy music wherever you go.

Sound that blows you away

- Superb gaming sound effects via Bluetooth
- DBB to preserve low tones for deep bass at any volume level
- Shielding technology to block mobile phone interference

Made to go places

- Elegant, slim and compact design to fit into any briefcase
- Robust aluminium finish and cover case for full protection

Truly portable and versatile

- Design fit for iPod/iPhone/iPad
- Built-in rechargeable Li-ion battery for long music playback
- Dock any iPod/iPhone/iPad, even in its case
- AUX-in for easy connection to almost any electronic device
- Free DockStudio app for Internet radio and other cool features

PHILIPS

Specifications

iPad compatibility

- Compatible with: iPad, iPad 2

iPhone compatibility

- Compatible with: iPhone, iPhone 3G, iPhone 3GS, iPhone 4

iPod compatibility

- Compatible with: iPod, iPod mini, iPod with colour display, iPod classic, iPod nano 1st Generation, iPod nano 2nd Generation, iPod nano 3rd Generation, iPod touch, iPod nano 4th Generation, iPod touch 2nd Generation, iPod nano 5th Generation, iPod touch 2nd Gen 8/16/32 GB, iPod 5th Generation, iPod nano 6th generation

iPod/iPhone/iPad App

- App name: DockStudio, Free download from App store
- Compatibility: iPod touch, iPhone, iPad iOS 4.3 or later
- 7000+ Internet radio stations
- 5-day weather forecast
- Playback: album/track navigation, playback controls
- Sound settings: DBB, DSC-Flat, Pop, Rock, Jazz, Classic
- Clock: analogue display, digital display
- Alarm: multiple alarms, sleep timer, wake up to music, wake up to sounds of nature, wake up to photos
- Battery status: speaker battery status

Connectivity

- Aux in

Audio Playback

- Cradle playback mode: Charging iPhone, Charging iPod, Charging iPad

Sound

- Output power (RMS): 14 W
- Sound Enhancement: Dynamic Bass Boost
- Sound System: Stereo
- Volume Control: Volume Control up/down

Loudspeakers

- Neodymium magnet system

Accessories

- Cables: 3.5 mm AUX-in

Power

- Power supply: 100-240 VAC, 50/60 Hz, Battery
- Battery Type: Built-in battery
- Operating time on battery: 10 hr

Dimensions

- Master carton weight: 2.3 kg
- Product dimensions (WxDxH): 310 x 110 x 40
- Weight incl. Packaging: 1.04 kg
- Master carton dimensions: 175 x 162 x 440 mm
- Master carton quantity: 2
- Weight: 0.76 kg

Highlights

Dynamic Bass Boost (DBB)



Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Superb gaming sound effects

The gaming experience isn't complete without great sound effects. Now, your games on a Smartphone or any other portable device can be made even more thrilling, thanks to Philips docking speaker that puts the boom in the sound. Hear all the sounds loud and clear, and boost your experience to new levels. What's more, you can do this with outstanding convenience, via Bluetooth. Simply establish a wireless Bluetooth connection between your portable device and the docking speaker, and play away.



Issue date 2014-03-19

Version: 5.1.8

12 NC: 8670 000 71544
EAN: 87 12581 57999 9

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com