

Philips
Mini Hi-Fi System

MP3/WMA

FWM75



wOOx Technology

Hear the bass, feel the difference

For those who value technology that enhances experiences, FWM75 has it all. Immerse yourself in the power of wOOx Technology and fully appreciate your favorite MP3 and WMA music in dynamic and rich sound.

Powerful sound you can hear and feel

- Class 'D' Digital Amplifier for quality sound performance
- 2 x 150W RMS/ 2 x 300W music power/4000W PMPO
- Front firing wOOx Technology speakers

Longer listening, greater enjoyment

- 3-disc changer for WMA/MP3-CD music playback
- Dual logic tape deck with auto replay
- 60 hours of WMA-CD or 30 hours of MP3-CD music playback

Ready for gaming

- Game port connection to your game console
- Game sound modes for different types of games
- MIX-IT for mixing the game sound with your favourite music

PHILIPS

sense and simplicity

Specifications

Sound

- **Output Power:** 2 x 300W music power
- **Sound Enhancement:** Class "D" Digital Amplifier, wOOx technology, Incredible Surround, Digital Sound Control, Virtual Ambience Control, Game Sound, MIX-IT

Loudspeakers

- **Main Speaker:** 3 way, Bass Reflex Speaker System, 6.5" woofer, wOOx bass radiator, 2" tweeter, Piezo, Speaker grilles detachable
- **Number of Loudspeakers:** 2

Audio Playback

- **Playback Media:** CD, CD-R, CD-RW, MP3-CD, WMA
- **Loader Type:** 3 CD Carousel
- **Number of Discs:** 3
- **Disc Playback Modes:** Fast Forward/Backward, Next/Previous Track Search, Repeat/one/all/program, Repeat/one/disk/program, 99-Track Programmable
- **Cassette Deck Technology:** Logic
- **Number of decks:** 2
- **Cassette Playback Modes:** Full Auto Stop

Audio Recording

- **Recording Media:** Tape
- **Tape Recording Enhancement:** CD Synchro Start Recording, Automatic Recording Level

Tuner/Reception/Transmission

- Auto digital tuning
- **Tuner Bands:** FM Stereo, MW
- **Tuner Enhancements:** Auto Store, Easy Set (Plug & Play)

- **Station presets:** 40
- **RDS:** Station Name, RDS Clock Set, Radio Text, Program Type, News

Connectivity

- **Aux in:** Line in, Game Port
- **Headphone:** 3.5 mm
- **Other connections:** Composite video (CVBS) out, FM Antenna, MW Antenna

Convenience

- **Alarms:** CD Alarm, Radio Alarm, Sleep timer
- **Clock:** On main display
- **Display Type:** FTD
- **Eco Power Standby:** 1 watt
- **Indications:** DIM mode, track, time, date, Cd functions, album number, album name

Accessories

- **Remote control:** 32-key with 2xAA batteries
- **Included Accessories:** AC Power Cord, FM/MW Antenna

Dimensions

- **Set dimensions (W x H x D):**
265 x 322 x 390 mm
- **Main speaker dimensions (W x H x D):**
240 x 358 x 230 mm
- **Packaging dimensions (W x H x D):**
624 x 412 x 510 mm
- **Weight incl. Packaging:** 20.5 kg

Power

- **Standby power consumption:** < 1W
- **Power supply:** 200-240 V, 50Hz

Product highlights

2x150W RMS/2x300W music power

Class D Amplifier

Class 'D' Digital Amplifier takes an analogue signal, converts it into a digital signal and then amplifies the signal digitally. The signal then enters a demodulation filter to give the final output. The amplified digital output delivers all the advantages of digital audio, including improved sound quality. In addition, Class 'D' Digital Amplifier has greater than 90% efficiency compared to traditional AB amplifiers. This high efficiency translates into a powerful amplifier with a small footprint.

Front firing wOOx Technology

3-disc changer for WMA/MP3-CD

60 hours of WMA-MP3-CD music

Dual logic tape deck

Game port connection

Game sound modes

MIX-IT for mixing game sound



Issue date 2007-12-07

Version: 3.0

12 NC: 9073 100 12442
EAN: 87 10895 86622 4

© 2007 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com