

Philips SoundBar Micro Hi-Fi System

SoundBar

HSB3280

# Bring your gaming experience to life

## with wireless subwoofer

The Philips SoundBar HSB3280 gives you powerful audio effects that your flat TV cannot deliver. The 1-piece integrated system with a wireless subwoofer requires no additional speakers or unruly wires for a truly immersive gaming experience.

### **Enrich your AV entertainment experience**

- Surround sound for different game genres
- USB Direct for easy MP3 music playback
- Front and rear AV input for easy hookup to game consoles

### Superb performance in a compact design

- · Digital wireless subwoofer for powerful bass
- Dolby Virtual Speaker for theater audio experience
- 300W RMS total output power
- Smartpower system syncs power status of TV and AV devices

## Design that blends into your interior

- · Desktop and wall mountable options for great convenience
- Single remote control for soundbar, TV and other AV devices



## HSB3280/37

## Specifications

#### Sound

- Output power (RMS): Total 300W RMS
- Sound System: Dolby Prologic II, Dolby Virtual speaker
- Loudspeaker types: Bass Reflex Speaker System
- Sound Enhancement: Digital Sound Control 4 modes

#### **Sound Enhancement**

- Game mode: Racing, Shooting, Sport, Arcade
- Movie mode: Action, Concert, Drama, Science Fiction

## **Connectivity**

- Front / Side connections: CVBS in, Audio L/R in, USB
- Rear Connections: Digital coaxial in 2x, Composite video (CVBS) output
- AV 1: CVBS in, Audio L/R in
- AV 2: CVBS in, Audio L/R in

## **Audio Playback**

- · Playback Media: USB flash drive
- Programmable Tracks: 20

#### **Remote Control**

 Programmable memory: 12 buttons for TV or other AV devices

## Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Antenna: FM Antenna
- Tuner Enhancements: Auto Store

#### · Auto digital tuning

• Station presets: 20

#### Loudspeakers

- Built-in speakers: 8
- Main Speaker: 2x1.5" tweeter, 6 x 1.5" Neodynium speaker
- Subwoofer type: Wireless subwoofer, Active

### Convenience

- Display Type: VFD display
- User convenience: Sleep Timer, Auto Power
- Clock/Version: Digital
- Eco Power Standby: 1 watt
- · Wall mountable / Ceiling Throw: Wall Mountable

#### Power

· Mains power

#### **Accessories**

 Included accessories: Wall mounting bracket, Remote Control, AC Power Cord, User Manual, Warranty certificate

#### **Dimensions**

- Set dimensions (W x H x D): 800 x 91 x 95 mm
- Set dimensions with stand ( $\dot{W} \times H \times D$ ): 800 x 100 x 100 mm
- Subwoofer dimensions (W  $\times$  H  $\times$  D):  $170 \times 378 \times 302$  mm
- Packaging dimensions (W x H x D): 397 x 375 x 354 mm













Issue date 2012-05-15

© 2012 Koninklijke Philips Electronics N.V. All Rights reserved.

Version: 3.0.7

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 8670 000 42662 UPC: 6 09585 16100 9

www.philips.com

# Highlights

#### Digital wireless subwoofer

The digital wireless subwoofer is optimized to reproduce bass frequencies. The result is a powerful reproduction of deep bass with the minimum of distortion.

### **Dolby Virtual Speaker**

Dolby Virtual Speaker is a sophisticated audio virtualization technology that produces rich and immersive surround sound from a two-speaker system. Highly advanced spatial algorithms faithfully replicate the sonic characteristics that occur in an ideal 5.1-channel environment. DVD playback is enhanced by expanding the 2-channel environment. When combined with Dolby Pro Logic II processing, any high quality stereo source is transformed into true-to-life, multi-channel surround sound. No need to purchase extra speakers, wires or speaker stands to appreciate room-filling sound.