

Philips  
Mini Hi-Fi System

MP3-CD playback

FWM139



## MP3-CD Playback

Fulfill all your music needs with FWM139 Mini Hi-Fi System, which delivers superbly rich sound plus 10 hours of MP3-CD music. You'll appreciate how easy it is to operate and control, sit back and relax, enjoy your music all day, your way!

### Enrich your sound experience

- 2 x 20W RMS/2 x 40W music power/ 800W PMPO
- 2-Way Bass Reflex Speaker System for powerful sound

### Continuous enjoyment of your favorite music

- 10 hours of MP3-CD music
- AM/ FM tuner for radio enjoyment
- Stereo cassette deck

### Personalized sound settings

- Dynamic Bass Boost for deep and dramatic sound
- Digital Sound Control for optimized music style settings

**PHILIPS**

# Specifications

## Sound

- Sound Enhancement: Dynamic Bass Boost, Digital Sound Control

## Loudspeakers

- Main Speaker: 4" woofer, Piezo, 2 way, Bass Reflex Speaker System
- Number of Loudspeakers: 2

## Audio Playback

- Number of Discs: 1
- Loader Type: Tray
- Playback Media: CD, CD-R, CD-RW, MP3-CD
- Disc Playback Modes: Repeat/one/disk/program, Shuffle Play, Fast Forward/Backward, Next/Previous Track Search, Repeat Play
- Programmable Tracks: 20
- Number of decks: 1
- Cassette Deck Technology: Mechanical
- Cassette Playback Modes: Automatic Stop

## Audio Recording

- Recording Media: Tape
- Tape Recording Enhancement: CD Synchro Start Recording

## Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, FM, MW

## Convenience

- Alarms: CD Alarm, Sleep timer
- Clock: On main display
- Display Type: LCD

## Connectivity

- Headphone: 2.5 mm

## Accessories

- Included accessories: Remote Control, Guarantee booklet
- User Manual: Printed 16 languages

## Dimensions

- Set dimensions (W x H x D): 220 x 292 x 285 mm
- Packaging dimensions (W x H x D): 510 x 350 x 416 mm
- Weight incl. Packaging: 9.333 kg

## Power

- Power supply: 200-240 V
- Standby power consumption: < 1 W



# Highlights

## 2x20W RMS/2x40W music power

2 x 20W RMS/2 x 40W music power/ 800W PMPO

## 2-Way Bass Reflex System

2-Way Bass Reflex Speaker System for powerful sound

## 10 hours of MP3-CD music

MP3 stands for "MPEG 1 Audio layer-3". MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. MP3 has become the standard audio compression format used on the world wide web, allowing quick and easy audio file transfer.

## AM/ FM tuner

AM/ FM tuner for radio enjoyment

## Stereo cassette deck

Stereo cassette deck

## Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

## Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.



Issue date 2014-02-05

Version: 2.0.5

12 NC: 9073 100 13503  
EAN: 87 10895 97960 3

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)