

Philips
DVD player

DVP5992



Get sharper, clearer pictures

with HDMI 1080p and WMV Playback

Be impressed with this Philips DVD player with HDMI digital video and audio connection. Step into another home entertainment arena as you immerse yourself with High Definition video (720p / 1080i/1080p).

Bring audio and video to life

- HDMI 1080p upscales to high definition for sharper pictures
- High definition JPEG playback for images in true resolution
- Progressive Scan component video for optimized image quality
- Screen Fit for optimal viewing every time

Play all your movies and music

- Windows Media Video for movie playback from your PC
- Play CD, (S)VCD, DVD, DVD+- R/RW, DivX, MP3, WMA, WMV, JPEG
- DivX Ultra Certified for enhanced DivX video playback

Connect and enjoy multiple sources

- Hi-Speed USB 2.0 Link plays video/music from USB flash drive

Easy to use

- My Wallpaper for a personalized welcome screen
- EasyLink to control all HDMI CEC devices via a single remote
- One-touch MP3 creation directly from CDs onto USB sticks

Highlights

HDMI 1080p



HDMI 1080p upscaling delivers images that are crystal clear. Movies in standard definition can now be enjoyed in true high definition resolution - ensuring more details and more true-to-life pictures. Progressive Scan (represented by "p" in "1080p") eliminates the line structure prevalent on TV screens, again ensuring relentlessly sharp images. To top it off, HDMI makes a direct digital connection that can carry uncompressed digital HD video as well as digital multichannel audio, without conversions to analog - delivering perfect picture and sound quality, completely free from noise.

Windows Media Video

With Windows Media Video, you can play PC video files on your TV. Enjoying these with friends and family also becomes a whole lot easier. Say goodbye to squinting at the computer screen, and lean back and enjoy your favorite WMV files on your TV - in the comfort of your living room.

DivX Ultra Certified



With DivX support, you are able to enjoy DivX encoded videos and movies from the Internet, including purchased Hollywood films, in the comfort of your living room. The DivX media format is an MPEG-4 based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW and DVD recordable disc for playback on your DivX Ultra Certified Philips Blu-ray or DVD player. DivX Ultra combines DivX playback with great features like integrated subtitles, multiple audio languages, multiple tracks and menus into one convenient file format.

Multimedia WMV

Play CD, (S)VCD, DVD, DVD+- R/RW, DivX, MP3, WMA, WMV, JPEG

High definition JPEG playback

High definition JPEG playback lets you view your pictures on your television in resolutions as high as two megapixels. Now you can view your digital pictures in absolute clarity, without loss of quality or detail - and share them with friends and family in the comfort of your living room.

Hi-Speed USB 2.0 Link

The Universal Serial Bus or USB is a protocol standard that is conveniently used to link PCs, peripherals and consumer electronic equipment. Hi-Speed USB devices have a data transfer rate of up to 480 Mbps - up from the 12 Mbps in original USB ones. With Hi-Speed USB 2.0 Link, all you have to do is plug in your USB device, select the movie, music or photo and play away.

EasyLink

EasyLink lets you control multiple devices like DVD players, Blu-ray players, soundbar speaker, Home theater and TV's etc. with one remote. It uses HDMI CEC industry-standard protocol to share functionality between devices through the HDMI cable. With one touch of a button, you can operate all your connected HDMI CEC enabled equipment simultaneously. Functions like standby and play can now be carried out with absolute ease.

One-touch MP3 creation

Convert the contents of your favorite CDs to MP3 files on your Philips product, and store it directly on a thumbdrive or on your portable media player through a USB cable. Enjoy the convenience of creating MP3 files right in your living room, without a PC, and even while the CD is playing.



asimpleswitch.com

Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas – Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.

Specifications

Picture/Display

- D/A converter: 12 bit, 108 MHz
- Picture enhancement: Progressive scan, High Def (720p, 1080i, 1080p), Video Upscaling(720p, 1080i/p)

Sound

- D/A converter: 24 bit, 192 kHz
- Signal to noise ratio: > 90
- Distortion and Noise (1kHz): > 65 dB
- Crosstalk (1kHz): > 70 dB
- Dynamic Range (1kHz): > 80 dB
- Sound System: Dolby Digital
- Frequency response: 30-20000 Hz

Video Playback

- Playback Media: CD, CD-R/CD-RW, Video CD/SVCD, DVD, DivX, DVD+R/+RW, DVD-R/-RW, DVD-Video
- Compression formats: MPEG1, MPEG2, DivX 3.11, DivX 4.x, DivX 5.x, DivX 6.0, DivX Ultra, WMV
- Video disc playback system: PAL, NTSC

Audio Playback

- Playback Media: CD, MP3-CD, MP3-DVD, CD-R/RW, WMA-CD, Audio CD
- Compression format: Dolby Digital, MP3, PCM, WMA
- MP3 bit rates: 32 - 320 kbps

Still Picture Playback

- Playback Media: DVD+R/+RW, DVD-R/-RW, CD-R/RW, Picture CD, Kodak Picture CD
- Picture Compression Format: JPEG
- Picture Enhancement: Flip photos, Rotate, Zoom, Slideshow with MP3 playback, High Definition

Resolution

Multimedia Applications

- Multimedia connections: USB memory class device
- Playback Formats: DivX, MP3, JPEG Still pictures

Connectivity

- Rear Connections: Analog audio Left/Right out, Composite video (CVBS) output, HDMI output, Digital coaxial out, Component Video out
- Progressive, Scart

Convenience

- Child Protection: Parental Control, Child Lock
- On-Screen Display languages: Danish, Dutch, English, Finnish, French, German, Italian, Norwegian, Portuguese, Spanish, Swedish, Turkish, Polish

Accessories

- Included accessories: 2 x AAA Batteries, Quick start guide, Remote Control, User Manual, Warranty Leaflet

Dimensions

- Set dimensions (W x H x D): 435 x 38 x 209 mm
- Packaging dimensions (W x H x D): 524 x 82 x 276 mm
- Set weight: 1.4 kg
- Weight incl. Packaging: 0 kg

Power

- Power supply: 50Hz, 230V
- Power consumption: < 12 W
- Standby power consumption: < 0.1 W



Issue date 2020-12-07

Version: 2.4.4

12 NC: 8670 000 59523
EAN: 87 12581 52217 9

© 2020 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com