



Philips
HiFi Stereo Headphone

SBCHP830

Home-Studio

Closed and powerful sound with closed headphone

This stereo monitoring headphone brings studio performance into your home for a perfect listening experience.

The perfect listening experience

- 40mm speaker driver delivers sound without distortion
- Closed acoustic system blocks out ambient noise
- The whole ear is covered to optimize sound quality

You'll forget you're wearing them!

- Self adjusting inner headband ensures a comfortable fit

Always ready

- 24k gold-plated adaptor for ultra reliable connection
- Curled cable is variable in length and tangle resistant
- Detachable cable extends product life and simplifies storage

PHILIPS
sense and simplicity

Specifications

Sound

- Acoustic system: Closed
- Frequency response: 20 - 20 000 Hz
- Impedance: 32 Ohm
- Magnet type: Neodymium
- Maximum power input: 1500 mW
- Sensitivity: 104 dB
- Speaker diameter: 40
- Voice coil: CCAW
- Diaphragm: Mylar dome

Connectivity

- Connector: 3.5 & 6.3 mm stereo
- Finishing of connector: 24k Gold-plated
- Cable length: 3 m
- Type of cable: OFC
- Cable Connection: One-sided
- Curled cable
- Detachable cable

Accessories

- Adaptor plug: 3.5-6.3 mm

Highlights

40 mm speaker driver

The 40 mm speaker driver is made of a composite mylar material for a highly sensitive yet powerful element that delivers sound without audible distortion.

Closed acoustic system

Sounds around you are perfectly blocked out while the sound from the headphone is kept in a sealed chamber for perfect quality. This makes the headphone great for monitoring during live music or recording sessions.

Full size design

Full-size earshells of these Philips headphones not only cover your whole ear for better sound quality, but also provide space for a larger, higher performance driver.

Self adjusting inner headband

The inner headband of these Philips headphones makes it easy to obtain a perfect fit for your head. The mechanism adjusts automatically for comfort.

24k Gold-plated adaptor

Be assured of a perfect connection and high-quality sound regardless of whether your audio devices are fitted with 3.5 or 6.35 mm jack sockets.

Curled cable

A curled cable means no tangling and the convenience of it always being the right length.

Detachable cable

A detachable cable is both convenient to store and easy to replace, so there is no need to buy a new headphone if the cable ever breaks.



Issue date 2013-02-01

Version: 1.0.2

12 NC: 9082 100 02551
EAN: 87 10895 80479 0

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com