

Philips
DVD player

DVP3005



See, hear, play everything

Does size matter? Ever heard of less is more? Introducing the best value DVD player. No complications! Just a simple set that plays practically any disc format, including your digital photos with absolutely no compromise to picture quality.

Great audio and video performance

- RGB on Scart single connection for high-quality video
- Progressive Scan component video for optimized image quality
- 12-bit/108MHz video processing for sharp, natural images
- 192kHz/24 bit audio DAC enhances analogue sound input

Plays it all

- Music: CD, CD-R/RW and MP3-CD
- Photos: Picture CD (JPEG)
- Movies: DVD, DVD+R/RW, DVD-R/RW, (S)VCD

Fits everywhere, goes anywhere

- Compact design
- Ultra-slim design

PHILIPS
sense and simplicity

Specifications

Picture/Display

- **Aspect ratio:** 16:9, 4:3
- **D/A converter:** 12 bit, 108 MHz
- **Picture enhancement:** Progressive Scan

Sound

- **D/A converter:** 192kHz/24-bit
- **Signal to noise ratio:** 90 dB
- **Distortion and Noise (1kHz):** 70 dB
- **Crosstalk (1kHz):** 80 dB
- **Dynamic Range (1kHz):** 90 dB
- **Sound System:** Dolby Digital

Video Playback

- **Playback Media:** CD, CD-R, CD-R/CD-RW, Video CD/SVCD, DVD+R, DVD+RW, DVD-R, DVD-RW (Video mode), DVD-Video
- **Compression formats:** MPEG1, MPEG2
- **Video disc playback system:** NTSC, PAL

Audio Playback

- **Playback Media:** CD, CD-R, MP3-CD, CD-RW
- **Compression format:** PCM, MP3
- **MP3 bit rates:** 32 - 256 kbps

Still Picture Playback

- **Playback Media:** Picture CD
- **Picture compression format:** JPEG
- **Picture enhancement:** Slideshow

Connectivity

- **Other connections:** Scart, ComponentVideo out, Progressive, Composite video (CVBS) out, Analogue audio Left/Right out, Digital coaxial out

Convenience

- **Child Protection:** Parental Control
- **On-Screen Display languages:** Dutch, English, French, German

Power

- **Power supply:** 220-240V, 50Hz
- **Power consumption:** 10 W
- **Standby power consumption:** < 0.8 W

Accessories

- **Batteries:** 2 x AA
- **Cables:** None
- **Remote control:** 3141 017 90221
- **User Manual:** English
- **Warranty Card**

Dimensions

- **Set dimensions (W x H x D):** 360 x 37 x 265 mm
- **Set weight:** 1.98 kg
- **Packaging dimensions (W x H x D):** 415 x 82 x 352 mm
- **Weight incl. Packaging:** 2.98 kg

Product highlights

Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

12-bit/108MHz video DAC

12-bit Video DAC is a superior Digital-to-Analogue-Converter that preserves every detail of the authentic picture quality. It shows subtle shades and smoother graduation of colours, resulting in a more vibrant and natural picture. The limitation of the usual 10bit DAC become in particular apparent while using large screens and projectors.

192kHz/24 bit audio DAC

192KHz sampling enables you to have an accurate representation of the original sound curves. Together with a 24-bit resolution, more information is captured from the original analogue sound wave form, giving a much richer audio reproduction.

RGB on Scart connectivity

RGB on Scart is a cable connection that provides easy connectivity for high quality video output.

Multi-format Movies

Multi format playability allows you to play most disc formats for maximum disc compatibility and viewing pleasure.

Multi-format Music

Multi format playability allows you to play most disc formats for maximum disc compatibility and listening pleasure.

Picture CD (JPEG)

Multi format playability allows you to view images in the comfort of your living room and play most disc formats for maximum disc compatibility and viewing pleasure.

Ultra-slim design

The attractive enclosure has a very low profile.



Issue date 2007-12-07

Version: 8.0

12 NC: 8622 810 12162
EAN: 87 10895 85719 2

© 2007 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com