





The ideal DVD player for your HDTV

with 1080p HDMI upconversion

Be impressed with this Philips DVD player with HDMI digital video and audio connection. Step into another home entertainment arena as you immerse yourself in High Definition video (720p/1080i/1080p).

Plays all your movies and music

- DivX Ultra Certified for enhanced playback of DivX videos
- Plays CD, (S) VCD, DVD, DVD+R/RW, DVD-R/RW
- Plays WMV, DivX, WMA, MP3 and HD JPEG photos

Brings audio and video to life

- HDMI digital output for easy connection with only one cable
- High definition JPEG playback for images in true resolution
- Progressive Scan component video for optimised image quality
- High-quality outputs for analogue and digital audio

Easy to use

- Create MP3s directly from CDs
- EasyLink for easy control of connected devices via HDMI CEC

Connect and enjoy multiple sources

• Hi-Speed USB 2.0 Link plays media from USB flash drives



Highlights

HDMI for simple AV connection

HDMI stands for High Definition Multimedia Interface. It is a direct digital connection that can carry digital HD video as well as digital multi-channel audio. By eliminating the conversion to analogue signals it delivers perfect picture and sound quality, completely free from noise. HDMI is fully backwardscompatible with DVI (Digital Video Interface).

DivX Ultra Certified

With DivX support, you can enjoy DivX encoded videos in the comfort of your living room. The DivX media format is an MPEG4based video compression technology that enables you to save large files such as movies, trailers and music videos on media, e.g. CD-R/ RW and DVD recordable discs. DivX Ultra combines DivX playback with great features including integrated subtitles, multiple audio languages, multiple tracks and menus into one convenient file format.

High definition JPEG playback

High definition JPEG playback lets you view your pictures on your television in resolutions as high as two megapixels. Now you can view your digital pictures in absolute clarity, without loss of quality or detail - and share them with friends and family in the comfort of your living room.

Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, it writes both fields at the same time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

Hi-Speed USB 2.0 Link



The Universal Serial Bus or USB is a protocol standard that is conveniently used to link PCs, peripherals and consumer electronic equipment. Hi-Speed USB devices have a data transfer rate of up to 480 Mbps - up from the 12 Mbps of original USB devices. With Hi-Speed USB 2.0 Link, all you have to do is plug in your USB device, select the movie, music or photo and play away.



DVP5992/37

Specifications

Picture/Display

- D/A converter: 12-bit, 108 MHz
- Picture enhancement: Progressive Scan, High Def (720p, 1080i, 1080p), Video Upscaling (720p, 1080i/p)

Sound

- D/A converter: 24-bit, 192 kHz
- Signal to noise ratio: > 90 dB
- Distortion and Noise (1 kHz): > 65 dB
- Crosstalk (1 kHz): > 70 dB
- Dynamic Range (1 kHz): > 80 dB
 Sound System: Dolby Digital
- Frequency response: 30-20,000 Hz

Video Playback

- Playback Media: CD, CD-R/CD-RW, Video CD/ SVCD, DVD, DivX, DVD+R/+RW, DVD-R/-RW, DVD-Video
- Compression formats: MPEG1, MPEG2, DivX 3.11, DivX 4.x, DivX 5.x, DivX 6.0, DivX Ultra, WMV
- Video disc playback system: PAL, NTSC

Audio Playback

- Playback Media: CD, MP3-CD, MP3-DVD, CD-R/ RW, WMA-CD, Audio CD
- Compression format: Dolby Digital, MP3, PCM, WMA
- MP3 bit rates: 32 320 kbps

Still Picture Playback

- Playback Media: DVD+R/+RW, DVD-R/-RW, CD-R/RW, Picture CD, Kodak Picture CD
- Picture compression format: JPEG
- Picture enhancement: Flip photos, Rotate, Zoom,

Slideshow with MP3 playback, High Definition Resolution

Multimedia Applications

- Multimedia connections: USB memory class device
- Playback Formats: DivX, MP3, JPEG Still pictures

Connectivity

 Rear Connections: Analogue audio Left/Right out, Composite video (CVBS) output, HDMI output, Digital coaxial out, ComponentVideo out Progressive

Convenience

- Child Protection: Parental Control, Child Lock
- On-Screen Display languages: American, Canadian French, Mexican Spanish

Accessories

 Included Accessories: 2 x AAA Batteries, Quick start guide, Remote Control, User Manual, Warranty Leaflet

Dimensions

- Set dimensions (W x H x D): $435 \times 38 \times 210$ mm
- Packaging dimensions (W x H x D):
- 490 x 82 x 296 mm
- Set weight: 1.4 kg

Power

- Power supply: 120 V, 60 Hz
- Power consumption: < 10 W
- Standby power consumption: < 1.0 W



Issue date 2009-04-12

 $\ensuremath{\textcircled{}^{\circ}}$ 2009 Koninklijke Philips Electronics N.V. All Rights reserved.

www.philips.com

Version: 1.0.6

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 8670 000 40789 UPC: 6 09585 15679 1 DVP5992/37