



Philips  
5.1 Home theater

200W RMS power  
DVD playback

HTS3011

## Simply sounds great

with compact speakers

This stylish and compact digital home entertainment system plays practically any disc in high quality Dolby Digital multi-channel surround sound. So just relax and fully immerse yourself in your favorite movies and music at home.

### Bring audio and video to life

- Dolby Digital and Pro Logic II surround sound
- 12-bit/108MHz video processing for sharp and natural images
- Advanced Class D Amplifier for compact, powerful sound
- Karaoke Scoring for fun and exciting song contests at home

### Play all your movies and music

- Plays CD, (S)VCD, DVD, DVD+R/RW, DVD-R/RW, DVD+R DL
- Plays DivX, MP3, WMA and JPEG digital camera photos
- Built-in FM tuner
- DivX Ultra Certified for enhanced playback of DivX videos

### Easy to set up

- Easy-fit™ connectors with color-coding for a simple set-up

# PHILIPS

# Highlights

## Plays it all

Play virtually any disc you want - whether they be CDs, (S)VCDs, DVDs, DVD+R, DVD-R, DVD+RW, DVD-RW or DVD+R DL. Experience unbeatable flexibility and the convenience of playing all your discs on the one device.

## Plays it all

Play virtually any media format you want - whether they be DivX, MP3s, WMA or JPEGs. Experience the unbeatable convenience of great playability, and the luxury of sharing media files on your TV or home theater system - in the comfort of your living room.

## Dolby Digital and Pro Logic II

A built-in Dolby Digital decoder eliminates the need for an external decoder by processing all six channels of audio information to provide a surround sound experience and an astoundingly natural sense of ambience and dynamic realism. Dolby Pro Logic II provides

five channels of surround processing from any stereo source.

## 12-bit/108MHz video processing

12-bit Video DAC is a superior Digital-to-Analogue-Converter that preserves every detail of the authentic picture quality. It shows subtle shades and smoother graduation of colors, resulting in a more vibrant and natural picture. The limitation of the usual 10bit DAC become in particular apparent while using large screens and projectors.

## Advanced Class D Amplifier

Advanced Class D Amplifier for compact, powerful sound

## Easy-fit™ connectors

Color-coded connectors provide a simple and user-friendly solution to connect the speakers and subwoofer to the center unit of the home entertainment system simply by plugging the connectors in the matching colored interface at the rear of the center unit.

## DivX Ultra Certified

With DivX support, you are able to enjoy DivX encoded videos in the comfort of your living room. The DivX media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, and DVD recordable discs. DivX Ultra combines DivX playback with great features like integrated subtitles, multiple audio languages, multiple tracks and menus into one convenient file format.

## Karaoke Scoring

Add a dash of fun to your Karaoke sessions with Karaoke Scoring. Allow your performance to be judged for further improvement, or for friendly competitions. Karaoke Scoring automatically rates your singing and gives you a humorous picture that is tied to how well you did. The fun never ends.



# Specifications

## Picture/Display

- D/A converter: 12 bit, 108 MHz
- Picture enhancement: Progressive scan

## Sound

- Total Power (RMS): 200 W
- Output power (RMS): 4 x 25W + 2 x 50W
- D/A converter: 24 bit, 192 kHz
- Frequency response: 180 - 18000 Hz
- Signal to noise ratio: >60 dB
- Sound System: Dolby Digital, Dolby Prologic II, Stereo
- Sound Enhancement: Class "D" Digital Amplifier, Night Mode
- Equalizer settings: Action, Classic, Concert, Drama, Gaming, Lounge, Rock, Sports

## Video Playback

- Playback Media: CD-R/CD-RW, DVD+R/+RW, DVD-R/-RW, DVD-Video, Video CD/SVCD
- Compression formats: MPEG1, MPEG2, DivX 3.11, DivX 4.x, DivX 5.x, DivX 6.0, DivX Ultra, MPEG4
- Video disc playback system: PAL, NTSC

## Audio Playback

- Playback Media: Audio CD, CD-R/RW, DVD+R/+RW, DVD-R/-RW
- Compression format: MP3, WMA
- MP3 bit rates: 32-256 kbps and VBR

## Still Picture Playback

- Playback Media: DVD+R/+RW, DVD-R/-RW, CD-R/RW
- Picture Compression Format: JPEG
- Picture Enhancement: Rotate, Zoom, Slideshow with music playback

## Tuner/Reception/Transmission

- Tuner Bands: FM
- No. of preset Audio Channels: 40

## Connectivity

- Rear Connections: Composite video (CVBS) output, FM Antenna, AUX in, Easy-Fit Speaker Connectors, Component Video output
- Front / Side connections: Microphone input 3.5mm jack

## Power

- Power supply: 110-240V, 50/60 Hz
- Standby power consumption: < 1 W
- Power consumption: 40 W

## Loudspeakers

- Satellite speaker drivers: 3" full range woofer

- Satellite speaker impedance: 4 ohm
- Satellite speaker freq range: 150-20000 Hz
- Center Speaker: Magnetically shielded
- Center speaker drivers: 3" full range woofer
- Center speaker impedance: 8 ohm
- Center freq range: 150-20000 Hz
- Subwoofer driver: 6.5" high efficiency woofer
- Subwoofer type: Passive
- Subwoofer impedance: 8 ohm
- Subwoofer freq range: 45 - 150 Hz

## Accessories

- Included accessories: Remote Control, 2 x AAA Batteries, CVBS video cable, FM antenna, User Manual, Quick start guide, World Wide Warranty leaflet

## Dimensions

- Set dimensions (W x H x D): 360 x 55 x 332 mm
- Set weight: 2.58 kg
- Surround Speaker dimensions (W x H x D): 100 x 95.5 x 83.5 mm
- Surround speaker Weight: 0.47 kg
- Center speaker dimensions (W x H x D): 100 x 95.5 x 83.5 mm
- Center Speaker Weight: 0.52 kg
- Subwoofer dimensions (W x H x D): 131 x 315.5 x 386 mm
- Subwoofer Weight: 3.6 kg
- Packaging dimensions (W x H x D): 570 x 310 x 392 mm
- Weight incl. Packaging: 10.4 kg

## Outer Carton

- EAN: 87 12581 38898 0
- Number of consumer packagings: 1
- Gross weight: 10.62 kg
- Outer carton (L x W x H): 56.2 x 39.4 x 30.7 cm
- Nett weight: 8.822 kg
- Tare weight: 1.798 kg

## Packaging dimensions

- EAN: 87 12581 38898 0
- Number of products included: 1
- Packaging type: Carton
- Packaging dimensions (W x H x D): 56.2 x 30.7 x 39.4 cm
- Gross weight: 10.62 kg
- Nett weight: 8.822 kg
- Tare weight: 1.798 kg

## Product dimensions

- Cable length: 0 cm
- Product dimensions (W x H x D): 0 x 0 x 0 cm
- Weight: 0 kg



Issue date 2014-02-10

Version: 2.0.6

12 NC: 8670 000 36278  
EAN: 87 12581 38898 0

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)