



Wireless speaker

- Bluetooth®
- 30 W Output Power
- 20 hours play time
- Built-in power-bank function

TAS7505/00

Beautiful music

Play what you love with the Bluetooth speaker that looks great in any setting. You get 20 hours play time and rich sound with warm bass. There's a power-bank function for charging phones, and the wool-blend speaker fabric adds style.

Benefits

Elegant, tactile design

- Form and function in perfect harmony
- Kvadrat speaker fabric. Designed to let the sound through
- Power-bank function. Charge a mobile via USB-A port
- Embossed buttons for vol, stereo pairing, and more

Plays well in bigger rooms

- 20 hours play time. 4.5 hours charging time
- Play it loud. Pair for stereo
- 3.57" full-range driver

- Bluetooth 5.0. Up to 20 m wireless range
- Passive radiator for strong bass

From living room to garden terrace

- Lanyard hole for a carrying strap or cord
- Dimensions: 230x87x85 mm
- IPX7-rated speaker driver. For peace of mind*



reddot winner 2020

PHILIPS

Features

Form and function in harmony



From morning workout to dinner on the balcony, this Bluetooth speaker does music in style. Embossed buttons let you control playback, stereo pairing, Bluetooth, and more. The speaker's lanyard hole is handy if you want to use a carrying strap.

Kvadrat speaker fabric

This speaker is covered with a premium speaker fabric created by high-end manufacturer Kvadrat. The beautiful wool-blend material is acoustically transparent, allowing the sound to flow freely from the speaker into the room.

20 hours play time



You get 20 hours play time from a single charge, and the wireless range is 20 m. Charging the speaker takes 4.5 hours, via the included USB-C cable.

Power-bank function



There's a handy USB-A port on the speaker that lets you use the speaker to charge a smart device. Bluetooth pairing is simple, and the speaker remembers the last device it was paired with.

Play it loud. Pair for stereo



A passive radiator delivers strong bass. The sound from the 3.57" full-range driver stays clear even at high volume. Want to make your music sound even bigger? Pair with an identical speaker for stereo sound.

Specifications

[field not found 'disclaimer_text']

Sound

Output power (RMS)	30W
Output power (MAX)	60W
Sound System	Mono
Frequency response	20 Hz - 20 KHz

Loudspeakers

Number of sound channels	1
Driver configuration	Full range
Number of full range drivers	1
Full range driver diameter	90mm

Connectivity

Bluetooth version	5.0
Bluetooth profiles	A2DP AVRCP
Bluetooth range	Line of sight, 20m or 66ft
USB charging	5V, 2A
DLNA Standard	No
Multiple speaker connection	Yes
Multiple speaker scenario	Stereo
Multiple speaker technology	TWS
Type of cable	USB charging cable (Type-C)

Compatibility

Smartphone/tablet APP control	No
-------------------------------	----

Convenience

Volume control	Digital up/down
Automatic power off	Yes
Ease of Installation	Automatic pairing
Water resistance	IPX7*
Built-in microphone	No
Display screen	No
Handsfree calling	No
Light Effect	No

Power

Battery type	lithium (built-in)
Battery Capacity	3.7V, 7500mAh
Operating time on battery	20 hr
Charging time	4.5 hr
Input	5V, 2A
Power bank	Yes, integrated
Output	5V, 2A

Accessories

Cable	USB charging cable
Included accessories	Quick install guide World Wide Warranty leaflet Warranty Card

Design and finishing

Color	Grey
-------	------

Product dimensions

Depth	8.5 cm
Depth	3.3 inch
Height	3.4 inch
Height	8.7 cm
Weight	1.905 lb
Weight	0.864 kg
Width	23 cm
Width	9.1 inch

Packaging dimensions

Depth	13.2 cm
Depth	5.2 inch
Gross weight	2.474 lb
Gross weight	1.122 kg

Height	3.9 inch
Height	9.8 cm
Nett weight	0.912 kg
Nett weight	2.011 lb
Number of products included	1
Packaging type	Box
Tare weight	0.21 kg
Tare weight	0.463 lb
Width	27.1 cm
Width	10.7 inch
EAN	48 95229 10876 9

UPC

UPC	8 40063 20205 4
-----	-----------------

* The IPX7 rating means the speaker driver can be submerged for up to 30 minutes at a depth of up to 1 m. The speaker fabric is not waterproof but can withstand a drop of water.



data subject to change
2023, June 20

Version: 12.2.2
EAN: 4895229108769

© 2023 Koninklijke Philips N.V.
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com