

Philips
Speaker Dock



SBD6000



Powerful stereo sound stage

Powerful XSL Acoustics

Enjoy the powerful and wide sound stage of the SBD6000. The speakers and dock for iPod easily slip into your bag so that you can enjoy your music with friends wherever you are and experience amazing rich bass even at low volume.

Powerful Sound

- Dynamic Bass Boost electronically enhances the low tones
- Built-in speakers featuring XSL Acoustics for dynamic sound
- Extra wide soundstage for 3-dimensional and realistic sound
- Metal speaker grill protects speaker drivers

Take your music with you

- Carrying pouch to protect your speakers when not in use
- Cable winding system with detachable cable for neat storage
- Lightweight, portable design for music enjoyment any time

Always ready to go

- Cable neatly stored when not in use
- Battery or AC power option for music enjoyment anywhere
- Store your receiver on the convenient docking station

PHILIPS

Specifications

Sound

- Frequency response: 100–18,000 Hz
- Impedance: 3 Ohm
- RMS Power rating: 2 x 3 W

Connectivity

- Connector: iPod dedicated

Convenience

- Power on indication
- Volume control
- Operating time: 10 hours

Accessories

- AC/DC Adapter
- Pouch

Power

- Battery type: AAA, LR03
- Adapter type: 9 V 1.5 A
- Battery voltage: 1.5 V
- Number of batteries: 6

Packaging dimensions

- Packaging dimensions (W x H x D):

- 26.5 x 22.5 x 11.5 cm
- Net weight: 0.586 kg
- Gross weight: 0.889 kg
- Tare weight: 0.303 kg
- EAN: 87 12581 31566 5
- Number of products included: 1
- Packaging type: Carton

Outer Carton

- Outer carton (L x W x H): 75.2 x 29.1 x 26.3 cm
- Net weight: 3.516 kg
- Gross weight: 7.139 kg
- Tare weight: 3.623 kg
- EAN: 87 12581 31570 2
- Number of consumer packages: 6

Inner Carton

- Inner carton (L x W x H): 27.2 x 24 x 24.5 cm
- Net weight: 1.172 kg
- Gross weight: 2.012 kg
- Tare weight: 0.84 kg
- EAN: 87 12581 31568 9
- Number of consumer packages: 2

Highlights

DBB Dynamic Bass Boost

Activate the Dynamic Bass Boost (DBB), and the low-end bass frequencies are electronically enhanced to achieve consistent sound reproduction, especially when the speaker volume is set at a low level. You hear impressive bass at all times.

XSL Acoustics

Enjoy dynamic sound and powerful bass performance from your ShoqBox with XSL Acoustics. Impressive sound is produced by combining bright, brisk treble and mid-range sound with elastic, powerful bass. Innovative use of high-tech materials like titanium cone and neodymium magnet delivers sound output that's nearly double the power of a traditional speaker driver of the same size. Precise tuning between the speaker driver, the small acoustic architecture and the circuitry ensures superbly dynamic sound and optimises bass performance from the smallest sound enclosure.

Carrying pouch

Look after your speaker and stop the cable getting tangled by storing it in this handy soft pouch when not in use.

Speaker cable management

With its unique design, cable storage is no longer an issue. Simply pack and go.



Issue date 2013-05-10

Version: 5.1.9

12 NC: 8670 000 26961
EAN: 87 12581 31566 5

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com