

Philips Micro Hi-Fi System

- Made for iPod
- MP3/WMA-CD playback

## MCM398D

# Enjoy your tunes in Hi-Fi sound quality

## Play and charge your iPod

You're in touch with the latest and the coolest — Philips MCM398D lets you play your iPod music out loud with the docking cradle! Enjoy great sound in a compact form factor that fits in any room.

## Play your iPod content out loud at home

- Play and charge your iPod simultaneously
- Single remote control for the system and iPod

## **Enrich your sound experience**

- Enjoy MP3/WMA music directly from your portable USB devices
- Play MP3/WMA-CD, CD and CD-RW
- Digital Sound Control for optimised music style settings
- Dynamic Bass Boost for deep and dramatic sound
- $2 \times 50$  W RMS and  $2 \times 100$  W music power

### Start the day your way

- Wake-up and sleep timer functions
- Digital tuning with 40 pre-set stations for extra convenience

## Refined in sound and look

- · Elegant wood-finished speakers
- Motorised CD loader for convenient access



# Highlights

## **USB Direct for MP3/WMA music**

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favourite moments with family and friends.

## **Digital Sound Control**

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses

graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

## **Dynamic Bass Boost**

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of

the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

















## Specifications

#### Sound

- Output Power: 2 x 50 W RMS/2 x 100 W music power
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost

### Loudspeakers

 Main Speaker: 2-way, Bass Reflex Speaker System, 4" woofer, Piezo tweeter, Speaker grilles detachable

## **Audio Playback**

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/programme, Shuffle Play
- ID3-tag support
- · Loader Type: Tray, Motorised
- USB Direct Modes: Fast Reverse/Fast Forward, Play/Pause, Previous/Next, Programme Play, Repeat, Shuffle, Stop
- Cradle playback mode: Charging iPod, Fast forward and reverse, Next and Previous track, Play and Pause

## Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- · Auto digital tuning
- RDS: Station Name, Radio Text, RDS Clock Set
- Station presets: 40
- Tuner Enhancements: Auto Store

## **Connectivity**

- · Aux in: Line in
- · Headphones: 3.5 mm

- Other connections: FM Antenna, Cradle connection
- USB: USB host

### Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer, USB alarm
- · Clock: On main display
- Display Type: LCD
- Eco Power Standby: 1 watt

#### **Accessories**

- Included accessories: FM antenna
- Remote control: 24-key remote with Lithium battery
- · Quick start guide: English
- User Manual: English
- · Cradle: Cradle and adapters for iPod

#### **Dimensions**

- Set dimensions (W  $\times$  H  $\times$  D): 152  $\times$  228  $\times$  273 mm
- Main speaker dimensions (W  $\times$  H  $\times$  D): 140  $\times$  228  $\times$  244 mm
- Packaging dimensions (W x H x D): 514 x 275 x 345 mm
- Weight incl. Packaging: 8.7 kg

#### Powe

• Power supply: 220-240 V, 50 Hz

## iPod compatibility

 Compatible with: iPod, iPod mini, iPod nano, iPod shuffle, iPod with colour display, iPod 5th Generation



Issue date 2013-05-10

Version: 1.0.5

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 8670 000 31593 EAN: 87 12581 34635 5

www.philips.com