



Philips  
Cordless phone answer  
machine

CD2552S

## HD Sound

for natural voice clarity

The natural voice quality of HD Sound makes phone conversations even more lifelike.

The outstanding speakerphone brings the CD2 series to the heart of family life.

Conversations really can be shared with everyone.

### **Never miss a call**

- Digital answering machine
- 15-minute recording time

### **Natural voice clarity**

- HD sound
- Speakerphone - Talk handsfree

### **Pure convenience**

- Bright illuminated display
- 100-name phonebook

### **Eco-designed**

- Very low energy consumption
- Automatic reduction of the emitted power

# PHILIPS

# Specifications

## Picture/Display

- Backlight
- Backlight color: Amber
- Display colors: Black & White
- Lines of text: 1
- Main Display Technology: STN
- Main Display Type: Alphanumerical

## Sound

- Handset ringers: Instrumental, Polyphonic
- Volume Control: Volume Control up/down

## Convenience

- Alarms: Alarm Clock
- Base Station keys: Answering machine keys, Paging key
- Battery charging indication
- Call Management: Call Waiting\*, Caller ID\*, Conference Call, Explicit Call Transfer, Microphone mute
- Ease of Use: Full Duplex Handsfree, Keypad Lock, Menu Control
- Multi base capability: 1
- Multi handset capability: Up to 5 handsets
- Signal strength indication
- Backlit keypad: No
- Speakerphone - talk handsfree

## Network Features

- Antenna: Integrated on base, Integrated on handset

- Compatible: GAP
- Dialing: Tone, Pulse

## Operator Requirements

- Name and Caller ID
- Caller ID on call waiting

## Answering Machine

- Plug & Play Answering machine
- Recording time capacity: Up to 15 min.

## Memory Capacity

- Call log entries: 20
- Phonebook: 100 names and numbers
- Redial List Capacity: 10

## Dimensions

- Base dimensions: 118.5 x 113 x 82.5mm
- Handset dimensions: 162 x 48 x 28.5mm

## Power

- Battery Capacity: 600 mAh
- Battery type: AAA NiMH
- Kind of Battery: Rechargeable
- Mains power: AC 220-240V - 50Hz
- Number of batteries: 2 per handset
- Standby time: Up to 150 hours
- Talk time: Up to 12 hours

# Highlights

## HD sound

Enjoy high quality conversation, with a level of clarity rarely heard before. Thanks to a high-quality speaker and to a real acoustic chamber, the audio spectrum reaches far beyond what's normally heard on a telephone.

## Speakerphone - Talk handsfree

Handsfree mode uses a built-in loud speaker to amplify the voice of the caller, allowing you to speak and listen during a call without holding the phone to your ear. This is especially useful if you want to share the call with others or take notes during a call.

## Very low energy consumption

Thanks to a high efficiency power supply, the overall energy consumption is reduced by more than 50% compared to a conventional power supply.



Issue date 2019-06-11

Version: 2.0.5

12 NC: 8670 000 35113  
EAN: 87 12581 37592 8

© 2019 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)