

Philips Original radio mini

with 30-pin connector for iPod/iPhone FM, dual alarm 4W



ORD2100C

Set the trend with the Original Radio mini

Enjoy all your music and the appealing retro design of the Philips Original radio mini. Play from your iPod/iPhone, while the radio charges and auto synchronizes its clock with your Apple device.

Enrich your sound experience

- Play and charge your iPod/iPhone simultaneously
- FM digital tuning
- Bass Reflex Speaker System delivers a powerful, deeper bass

Easy to use

- Dock any iPod/iPhone, even in its case
- · Free HomeStudio app for enhanced wake-up & radio experiences
- · Auto clock synchronization with iPod/iPhone when docked
- Dual alarm to wake you and your partner at different times
- · Gentle wake for a pleasant wake up experience
- Sleep timer for easy falling asleep to your favorite music
- Audio-in for easy portable music playback

Contemporary retro design

· Contemporary reinterpretation of the iconic Philetta design



Original radio mini with 30-pin connector for iPod/iPhone, FM, dual alarm, 4W

Highlights

Play & charge your iPod/iPhone



Enjoy your favorite MP3 music while charging your iPod/iPhone! The dock lets you connect your portable device directly to the Docking entertainment system so you can listen to your favorite music in superb sound. It also charges your iPod/iPhone while it plays so you can enjoy your music and not have to worry about your portable player battery running out. The Docking entertainment system automatically charges your portable device while it is docked.

FM digital tuning



FM digital tuning

Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box

system. It differs from a conventional

loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

Dock iPod/iPhone in its case



Smartly designed spring-loaded docking port effortlessly accommodates any iPod or iPhone, without special adaptors. What's more, it works even when most protective cases are on – just dock your iPod or iPhone as it is. Now you can truly have fuss-free enjoyment of your music.

Free HomeStudio app



There's no better way to wake up or listen to the radio than with the free Philips HomeStudio app. Simply download the app from the Apple App Store to enjoy a host of exciting features. Advanced alarm set up, for example, gives you greater flexibility in alarm settings - including alarm volume, duration, date and sound. You also get better user interface when you listen to the radio, with easy-to-use station preset functions.

Auto clock synchronization



When connect and dock, this docking system will automatically synchronize the clock with your iPod/iPhone within a few seconds. With this convenient feature, you do not need to set the time manually.

AUDIO-IN (3.5mm)



Make one easy connection and enjoy all your music from portable devices and computers. Simply plug your device to the AUDIO-IN (3.5 mm) port on your Philips set. With computers, the connection is typically made from the headset output. Once linked, you can enjoy your entire music collection directly, on a set of superior speakers. Philips simply delivers better sound.











iPod compatibility

• Compatible with: iPod touch 4th generation, iPod touch 3rd generation, iPod touch 2nd Generation, iPod nano 6th generation, iPod nano 5th Generation, iPod nano 4th Generation, iPod classic, iPod with color display, iPod nano, iPod mini

iPhone compatibility

• Compatible with: iPhone 3G, iPhone 3GS, iPhone 4, iPhone 4S

iPod/iPhone App

- App name: HomeStudio, Free download from App store
- Compatibility: Dock radio for iPod/iPhone, iPod Touch, iPhone
- 5-day weather forecast
- Playback: album/track navigation, playback controls
- Clock: analog display, digital display
- Alarm: multiple alarms, sleep timer
- Radio: FM radio, scan, tune, preset

Audio Playback

• Playback mode: Charging iPod, Charging iPhone

Tuner/Reception/Transmission

- Tuner bands: FM
- Frequency range: (FM) 87.5-108 MHz
- Station presets: 20, via HomeStudio App
- Auto digital tuning

Alarm

- No. of alarms: 2
- Alarm source: Dock, FM radio, Buzzer
- Snooze (repeat alarm): Yes, 9mins
- Sleep timer: 15/ 30/ 60/ 90/ 120 mins

Connectivity

• Audio in (3.5mm)

Convenience

- Display Type: LCD white
- Display brightness: High/ Mid/ Low

Sound

- Sound System: Mono
- Volume control: rotary (digital)

. .

- LoudspeakersBuilt-in speakers: 1
- Built-III speake

Power

Power type: AC input

Dimensions

- Product dimensions (WxDxH): 245 x 133 x 122 mm
- Packaging dimensions (WxDxH): 336 x 158 x 183 mm

Accessories

 Included accessories: User Manual, Warranty certificate



© 2014 Koninklijke Philips N.V. All Rights reserved.

www.philips.com

Version: 3.0.3

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 000 96366 EAN: 00 60958 52298 08 ORD2100C/37