

Philips Classic micro music system

Dock for iPod

DAB+

DCB146



Obsessed with sound

Relax to great music

Enjoy music from your iPod, CD and from interference-free DAB+ radio on the sleek Philips Micro music system. With the handy all-in-one remote control, you can easily maximise your music pleasure - from multiple sources.

Enjoy digital quality DAB radio

- Clear and crackle-free DAB+ radio
- DAB+, DAB and FM for full radio experience

Enjoy your music from multiple sources

- · Play and charge your iPod simultaneously
- Play CD, CD-R and CD-RW

Easy to use

- Wake-up and sleep timer functions
- Digital tuning with 20 pre-set stations for extra convenience



Specifications

Audio Playback

- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/programme, Fast Forward/Reverse, Next/Previous Track Search, Repeat Play, Shuffle Play
- Loader Type: Top
- Cradle playback mode: Charging iPod, Fast forward and reverse, Next and Previous track, Play and Pause

Sound

- Output Power: 2 x 2 W RMS/2 x 4 W music power
- Volume Control: Volume Control up/down
- · Sound Enhancement: Dynamic Bass Boost
- Sound System: Stereo

Loudspeakers

• Main Speaker: 3" woofer

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW
- · Auto digital tuning
- Station presets: 20
- DAB: Band III, Info display, Menu, Smart Scan
- RDS: Programme Type, Radio Text, Station Name

Connectivity

- Headphones: 3.5 mm
- Other connections: Fixed FM and DAB T-shape antenna, MW Antenna
- Audio Connections: 3.5 mm Line in













Convenience

- Alarms: Sleep timer, Radio Alarm, CD Alarm
- · Clock: On main display
- Display Type: LCD
- Backlight colour: Blue
- · Backlight

Accessories

- Included accessories: FM/MW Antenna, Remote Control, World Wide Warranty leaflet, DAB antenna
- Remote control: 24-key remote control
- Cradle: Cradle and adapters for GoGear and iPod
- User Manual: English
- Quick start guide: English

Dimensions

- Set dimensions (W \times H \times D): 148 \times 233 \times 216 mm
- Main speaker dimensions (W x H x D): 134 x 230 x 152 mm
- Packaging dimensions (W x H x D): 326 x 270 x 370 mm
- Weight incl. Packaging: 4.75 kg

Power

• Power supply: 220-240 V, 50 Hz

iPod compatibility

 Compatible with: iPod, iPod classic, iPod mini, iPod nano, iPod nano 1st Generation, iPod nano 2nd Generation, iPod nano 3rd Generation, iPod nano 4th Generation, iPod nano 5th Generation, iPod nano 6th generation, iPod with colour display, iPod 5th Generation

Highlights

Play and charge your iPod



Enjoy your favourite MP3 music while charging your iPod! The dock lets you connect your iPod directly to the Docking entertainment system so you can listen to your favourite music in superb quality. It also charges your iPod while it plays so you can enjoy your music and not have to worry about your iPod battery running out. Use the remote control to navigate, select and playback the music stored on your iPod. The Docking entertainment system automatically charges your iPod while it is docked.

DAB+, DAB and FM

DAB+/DAB (Digital Audio Broadcasting) digital radio is, on top of FM analogue transmission, a new way of broadcasting radio via a network of terrestrial transmitters. It provides listeners with more choices and information delivered in clear and crackle-free sound quality. The technology allows the receiver to lock on to the strongest signal it can find. With DAB+ or DAB digital stations there are no frequencies to remember, and sets are tuned by station name, so there is no retuning on the move.



Issue date 2012-03-26

Version: 2.0.5

© 2012 Koninklijke Philips Electronics N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 8670 000 65716 EAN: 87 12581 55445 3

www.philips.com