



Philips Design collection  
Cordless phone with  
answering machine

**Slim line**  
2 handsets  
Black

**ID5552B**

## Design collection

When beauty is the call, the ID555 is the answer. This "Design collection" phone is made to delight the senses with its elegant, slim lines and a pure sound to match. The ID555 is the perfect addition to the most exclusive home interior.

### **Exclusive design**

- Stylish black glossy finish
- Extra slim design

### **Never miss a call**

- Digital answering machine
- 30-minute recording time
- Message counter on Base

### **Pure convenience**

- Bright blue illuminated display and keypad
- 200-name phonebook
- Speakerphone - Talk hands-free

### **Eco-designed**

- Very low energy consumption
- Automatic reduction of the emitted power

## Specifications

### Picture/Display

- Backlight
- Backlight colour: Blue
- Display colours: Black and White
- Lines of text: 5
- Main Display Technology: FSTN
- Main Display Type: Full Graphic

### Sound

- Handset ringers: Polyphonic
- Volume Control: Volume Control up/down

### Convenience

- Alarms: Alarm Clock
- Base Station keys: Answering machine keys, Paging key
- Battery charging indication
- Call Management: Call Waiting\*, Caller ID\*, Conference Call, Explicit Call Transfer, Microphone mute
- Ease of Use: Keypad Lock, Menu Control
- Function: Easy Call
- Multi-base capability: 1
- Multi-handset capability: Up to 5 handsets
- Signal strength indication
- VIP group with own melody: Yes for each phonebook entry
- Backlit keypad: Yes (Blue)
- Speakerphone — talk hands-free

### Network Features

- Antenna: Integrated on base, Integrated on handset
- Compatible: GAP
- Dialling: Tone, Pulse

### Operator Requirements

- Name and Caller ID
- Caller ID on call waiting

### Answering Machine

- Plug and Play Answering machine
- Recording time capacity: Up to 30 min.
- Message counter on base

### Memory Capacity

- Call log entries: 50
- Phonebook: 200 names and numbers
- Redial List Capacity: 10

### Dimensions

- Base dimensions: 128 x 69 x 85 mm
- Handset dimensions: 144 x 43 x 14.5 mm

### Power

- Battery capacity: 500 mAh
- Kind of Battery: Rechargeable
- Mains power: AC 220-240 V - 50 Hz
- Number of batteries: 1 battery pack per handset
- Standby time: Up to 130 hours
- Talk time: Up to 10 hours

## Highlights

### Speakerphone - Talk hands-free

Hands-free mode uses a built-in loudspeaker to amplify the voice of the caller, allowing you to speak and listen during a call without holding the phone to your ear. This is especially useful if you want to share the call with others or take notes during a call.

### Very low energy consumption

Thanks to a high efficiency power supply, the overall energy consumption is reduced by more than 50% compared to a conventional power supply.

### Automatic power reduction

Thanks to an intelligent embedded system, the transmitted power is permanently controlled and optimised depending on the distance between handset and base unit.



Issue date 2015-02-04

Version: 2.0.6

12 NC: 8670 000 41202  
EAN: 87 12581 43406 9

© 2015 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)