



Philips Prestigo  
Remote Control

PRESTiGo

SRU8112



## Direct access to your favorite channels

Easily select your favorite channels with our color icon-based universal remote! Blending technology and convenience, the Prestigo SRU8112 provides direct access buttons to your TV channels as well as big buttons for ease of use.

### Single control solution for most devices & brands

- Extensive infrared code database for most devices & brands
- Extensive library of channel icons for easy selection
- Control up to 12 devices out of choice of 24

### Quick and easy set-up

- No manual needed for setup
- Convenient IR learning from another remote
- Easily add and label extra functionality

### Smart intuitive use

- Activities to control multiple devices with one button press
- Big buttons increase operability and readability
- Selection buttons conveniently located next to screen
- Easy-to-read 5.1 cm (2.0") color LCD display

**PHILIPS**  
sense and simplicity

# Specifications

## Convenience

- Ease of Installation: Autosearch
- Languages in manual: English, French, Spanish
- Number of keys: 59
- Supported devices: TV, VCR, DVD, SAT, CABLE, CD/MD, RECEIVER, AMP, TIVO, Home Theater, PC, TAPE, DVR, DSS, AudioSet, Digital Media Receiver, Drapes/blinds (IR), DTT, DVD Recorder, DVDR-HDD combo, DVD-VCR combo, Game console, HTS, HVAC & Fans (IR), Lighting (IR), Projector (IR), Satellite Radio, Tuner, TV-DVD combo, TV-VCR combo, TV-VCR-DVD combo, VCD, Laser Disk
- On-Screen Display languages: English, German, French, Spanish
- Battery low indication
- Programmable macros: Yes, 26
- Display Type: LCD
- Channel icon library: 500
- Number of activities: 26
- Programmable channel icons: 100

## Power

- Battery type: AA / LR6 Alkaline
- Number of batteries: 3
- Battery saving manager: Auto switch on/off

## Infrared Capabilities

- Operating distance: 33 ft (10 m)
- Learning IR codes

- Transmitting LEDs: 2
- Carrier frequency range: 19kHz - 455 kHz
- Transmission angle: 90 degree

## Packaging dimensions

- UPC: 6 09585 15759 0
- Number of products included: 1
- Packaging type: Blister
- Packaging dimensions (W x H x D): 16 x 32.2 x 4.6 cm
- Nett weight: 0.152 kg
- Gross weight: 0.36 kg
- Tare weight: 0.208 kg

## Outer Carton

- GTIN: 2 06 09585 15759 4
- Number of consumer packagings: 6
- Outer carton (L x W x H): 34.5 x 30.5 x 19.5 cm
- Nett weight: 0.912 kg
- Gross weight: 3.92 kg
- Tare weight: 3.008 kg

## Inner Carton

- GTIN: 1 06 09585 15759 7
- Number of consumer packagings: 3
- Inner carton (L x W x H): 33 x 14.5 x 16.5 cm
- Nett weight: 0.456 kg
- Gross weight: 1.2 kg
- Tare weight: 0.744 kg

# Highlights

## Guided setup

Unlike other universal remote controls, where a 3-digit code needs to be input to identify a brand and device, this remote incorporates on-device step-by-step instructions to setup your equipment, regardless of brand.

## Learning functionality

Learning functionality refers to the process through which a remote control captures and stores infrared signals from other remotes for later use. When device codes are not included in the on-board database, they can always be learned from the original remote, simply by pointing to it.

## Universal IR code database

A universal IR code database refers to a library of infrared codes built-in to a particular remote. This feature allows a remote to control your equipment without needing to learn individual signals. Select the correct infrared code sets in the database for the devices you want to control, to enable control of virtually every audio/video system element on the market today – regardless of model or brand.



Issue date 2011-06-07

Version: 1.5.4

12 NC: 8670 000 41076  
UPC: 6 09585 15759 0

© 2011 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)