

Philips 2000 series  
In-ear true wireless  
headphones

6mm drivers/ closed-back  
Bluetooth®

TAT2205WT



## Always ready to go

Is there anything more useful than true wireless headphones with a charging case that fits in the pocket of your slim-fit jeans? These splash- and sweat-resistant in-ear headphones give you great sound and up to 12 hours play time.

### **Extremely convenient, super-small charging case**

- 4 hrs per charge. 15-min charge for 1 hr play time
- 6 mm neodymium drivers. Clear sound, punchy bass
- IPX4 splash- and sweat-resistant
- Super-small charging case for up to 12 hours play time

### **Easy pairing. Voice control.**

- Smart pairing. Automatically find your Bluetooth device
- Easily wake your smartphone's voice assistant
- Earbud switches to control music and calls
- Switch from music to phone calls with built-in microphone

### **Snug, lightweight design**

- Secure, comfortable fit
- Soft ear-tip covers in small, medium, and large

# PHILIPS

In-ear true wireless headphones  
6mm drivers/ closed-back Bluetooth®

# Specifications

## Sound

- Acoustic system: Closed
- Speaker diameter: 6mm
- Diaphragm: PET
- Impedance: 16 Ohm
- Magnet type: NdFeB
- Frequency response: 20 - 20 000 Hz
- Sensitivity: 90 dB

## Connectivity

- Microphone: Built-in microphone
- Bluetooth version: 5.1
- Bluetooth profiles: A2DP, HFP, HSP, AVRCP
- Maximum range: Up to 10 m

## Outer Carton

- Length: 37.5 cm
- Number of consumer packagings: 24
- Width: 27.5 cm
- Gross weight: 4.25 kg
- Height: 24.5 cm
- GTIN: 1 48 95229 10993 0
- Nett weight: 0.768 kg
- Tare weight: 3.482 kg

## Convenience

- Call Management: Answer/End Call, Reject Call, Switch between 2 calls

## Inner Carton

- Length: 18.7 cm
- Number of consumer packagings: 3
- Width: 12.8 cm
- Height: 10.4 cm
- Nett weight: 0.096 kg
- Gross weight: 0.5 kg

- Tare weight: 0.404 kg
- GTIN: 2 48 95229 10993 7

## Power

- Battery type: Lithium-Ion
- Rechargeable
- Music play time: 4+8 hour(s)
- Standby time: 50 hr
- Talk time: 3 hr

## Packaging dimensions

- Height: 18 cm
- Width: 9.5 cm
- Depth: 4 cm
- Number of products included: 1
- EAN: 48 95229 10993 3
- Gross weight: 0.153 kg
- Nett weight: 0.032 kg
- Tare weight: 0.121 kg

## Product dimensions

- Height: 2.9 cm
- Width: 5.5 cm
- Depth: 3.7 cm
- Weight: 0.032 kg

## Accessories

- Quick Start Guide
- USB cable: USB (Type-A to Type-C) cable
- Ear caps: 3 Sizes

## Design

- Color: White

## UPC

- UPC: 8 40063 20127 9

TAT2205WT/00

# Highlights

## IPX4

The small charging case couldn't be more convenient, and these true wireless headphones are also resistant to splashing from any direction. They won't mind a little sweat, and you don't need to worry about getting caught out in the rain.

## Super-small charging case

Hit the road with multiple charges in your pocket. You get up to 4 hours play time from a single charge, plus 8 extra hours from a fully charged case. A short 15-minute charge in the case gives you an hour of play time. A full charge of the case takes 2 hours via USB-C.

## Secure, comfortable fit

You get great sound from the 6 mm neodymium drivers and you can rock your tunes in real comfort thanks to the snug, lightweight design. Soft, interchangeable ear-tip covers help you find a comfortable in-ear fit.

## Earbud switches

A button on each earbud makes it easy to control your listening. Skip or pause tracks, take or reject calls and more.

## Voice assistant

Wake your phone's voice assistant without touching your phone. Ask smartphone's voice assistant to play music, get directions and check informations, and more.

## Smart Bluetooth pairing.

These earphones are ready to pair the instant you take them out of their charging case. Once they're paired, the earphones remember the last device they were paired with.

## 4 hrs per charge.

4 hrs per charge. 15-min charge for 1 hr play time

## 6 mm neodymium drivers.

6 mm neodymium drivers. Clear sound, punchy bass

## Soft ear-tip

Soft ear-tip covers in small, medium, and large

## Switch from music to calls

Switch from music to phone calls with built-in microphone



Issue date 2024-03-08

Version: 7.4.4

EAN: 48 95229 10993 3

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)