

Always there to help you  
Register your product and get support at  
[www.philips.com/welcome](http://www.philips.com/welcome)

Question?  
Contact  
Philips



EN Short User Manual  
KO 요약 사용 설명서  
TH คู่มือผู้ใช้ข้อย่างย่อ

PHILIPS



2014 © WOOX Innovations Limited. All rights reserved.  
Philips and the Philips' Shield Emblem are registered trademarks of  
Koninklijke Philips N.V. and are used by WOOX Innovations Limited  
under license from Koninklijke Philips N.V.

MCM2150\_98\_Short User Manual\_V2.0



**PHILIPS**

Before using your product, read all accompanying safety information.

- 
- 
- 

**PHILIPS**

Switch to standby mode

Switch to ECO standby mode

**PHILIPS**

1 CD

2 4

**PHILIPS**

2

1 USB

**PHILIPS**

**Tune to a radio station**

1 FM

2 A 2 sec. 97.1 101.5

2 B 101.5 101.6

**Program radio stations automatically**

1 FM

2 PROG 2 sec. P01 P20

3 ▲/▼

**Program radio stations manually**

1 FM

2 PROG 101.5

3 ▲/▼ P01

4 PROG P02

**Control play**

▲/▼	Select a folder.
◀/▶	Select an audio file.
⏸	Pause or resume play.
■	Stop play.
REPEAT	Play a track or all tracks repeatedly.
SHUFFLE	Play tracks randomly.
VOL +/-	Increase or decrease the volume.
MUTE	Mute or restore sound.
SOUND	Enrich sound effect with DSC: balanced, clear, powerful, warm, and bright.
DISPLAY	Adjust display brightness.

**PHILIPS**

**CLOCK**

1 CLOCK 3 sec.

2 ◀/▶

3 CLOCK

Repeat steps 2-3 to set hour and minute.

**PHILIPS**

**TIMER SLEEP**

1 TIMER SLEEP 3 sec.

2 ◀/▶

3 TIMER SLEEP

Repeat steps 2-3 to set minute, select a source (CD, FM, or USB), and adjust volume.

**PHILIPS**

**AUDIO IN**

1

2

**Specifications**

Maximum Output Power	70 W
Tuning Range	87.5-108 MHz
Tuning grid	50 KHz
USB Direct Version	2.0 full speed
USB 5 V Power	≤500 mA
Disc Diameter	12 cm/8 cm
Support Disc	CD-DA, CD-R, CD-RW, MP3-CD
AC power	100-240 V~, 50/60 Hz
Operation Power Consumption	100 W
Eco Standby Power Consumption	<0.5 W
Dimensions	
- Main Unit (W x H x D)	180 x 121 x 239 mm
- Speaker Box (W x H x D)	140 x 260 x 185 mm
Weight	
- Main Unit	1.6 kg
- Speaker Box	2 x 2.1 kg

**Compatible USB devices:**

- USB flash memory (USB2.0 or USB1.1)
- USB flash players (USB2.0 or USB1.1)
- memory cards (requires an additional card reader to work with this unit)

**Supported formats:**

- USB or memory file format: FAT12, FAT16, FAT32 (sector size: 512 bytes)
- MP3 bit rate (data rate): 32-320 Kbps and variable bit rate
- Directory nesting up to a maximum of 8 levels
- Number of albums/ folders: maximum 99
- Number of tracks/titles: maximum 999
- File name in Unicode UTF8 (maximum length: 32 bytes)

**Supported MP3 disc formats**

- ISO9660, joliet
- Maximum title number: 128 (depending on file name length)
- Maximum album number: 99
- Supported sampling frequencies: 32 kHz, 44.1 kHz, 48 kHz
- Supported Bit-rates: 32-256 (kbps), variable bit rates

