

# Compelling sound quality

## Authentic sound for multimedia enjoyment



The MMS221 speaker system is the easy way to add an authentic stereo experience to your music, Internet and multimedia PC applications.

**Your computer never sounded so good**

- Enjoy PC audio with the quality of a home audio system
- Over 75 years of audio experience

**Experience true multimedia**

- Compatible with music, games, film & Internet audio sources
- Easy to connect to either a PC or a laptop

**Hear every detail**

- Bass reflex speakers deliver a powerful, deeper bass
- Digital Dynamic Bass Boost for optimised bass at any volume

**Easy to use**

- Labelled and colour coded connectors get you going in minutes
- Headphone jack for better personal music enjoyment
- Magnetic Shielding eliminates computer screen distortion



# PHILIPS

## Technical specifications

### Sound

- **Bass enhancement:** Digital Bass boost
- **Frequency response:** 120 - 20 000 Hz
- **Output power (RMS):** 2 x 1.5W
- **Music power:** 6 W
- **Volume Control:** Analogue volume control
- **Wires:** Fixed wires

### Loudspeakers

- **Loudspeaker enhancement:** Magnetic shielded LSB

### Connectivity

- **Headphone:** 3.5 mm
- **Power:** Built in transformer

### Convenience

- Power on indication

### Accessories

- **Included accessories:** Quick install guide

### Power

- **Power LED indicator:** Blue

## Product highlights

### Home audio quality on the PC

Philips has used over 75 years experience at the leading edge of audio to create PC audio products with the same performance as our award winning home audio systems.

### Music, games, films, Internet

All types of music, games, films and Internet audio sources can be played, so no matter what you want to hear, we make your multimedia experiences sound more involving than ever.

### Bass reflex speaker system

Bass reflex speaker system delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimise the low frequency roll off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

### Digital Dynamic Bass Boost

Digital Dynamic Bass Boost is an intelligent bass booster that delivers maximum bass enhancement at high volumes without sound distortion and at low volumes without compromising on bottom end bass frequencies. Technologically advanced electronics constantly monitor volume and bass levels, precisely calibrating both to prevent sound distortion, thus producing optimised bass. Digital Dynamic Bass Boost enables the enjoyment of superb bass performance - regardless of the chosen volume level.

### Quick set up

Colour coded cables, clear labelling and easy to understand documentation mean you'll be up and running in minutes

### For PC or laptop

Can be connected to either a PC or a laptop

### Headphone jack

### Magnetic Shielding

Because the powerful magnets in speaker drivers are magnetically shielded, there's no danger of image distortion or damage when placed close to your PC monitor screen.

### 75 years of audio experience

Philips invented the CD, led the team that wrote the USB audio specification and has produced millions of audio systems, home cinema sets and TV's over many decades. As a leader in audio innovation, you can trust Philips to make PC sound systems of the highest sound quality.



Date of issue 2005-12-27

Version: 1.0

12 NC: 9082 100 03482  
EAN: 87 10895 84718 6

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.  
© 2005 Koninklijke Philips Electronics N.V.  
All Rights reserved.  
[www.philips.com](http://www.philips.com)