

Philips 2000 series  
In-ear true wireless  
headphones

6mm drivers/ closed-back  
Bluetooth®  
Black

SHB2515BK



## Tune after tune after tune

Be free. These true wireless in-ear headphones offer a mammoth 100 hours of play time thanks to their portable charging case. Enjoy great sound tune after tune, and direct access to your phone's virtual assistant. Did someone say road trip?

### **Cut loose. 70 hours of play time. No wires.**

- 6 mm neodymium acoustic drivers. Great sound, punchy bass
- Get up to 70 hours play time or talk time with the case
- Portable charging case with built-in 3350 mAH power bank
- USB port on charging case. Charge your phone on the go

### **Feels good. Looks good.**

- Ear-tip covers in small, medium, and large-for a perfect fit
- Mono mode for when you want to leave one ear free
- Oval acoustic tube. Comfort and passive noise isolation
- Soft rubberized wing tips. Secure and comfortable

### **Easy pairing. Voice control.**

- A double button-press wakes your phone's voice assistant
- Built-in mic with echo cancellation for clear audio
- Smart pairing. Automatically find your Bluetooth device
- Multi-function button. Easily control music and calls

# PHILIPS

In-ear true wireless headphones  
6mm drivers/ closed-back Bluetooth®, Black

# Specifications

## Sound

- Impedance: 16 Ohm
- Frequency response: 20 - 20 000 Hz
- Speaker diameter: 6 mm
- Sensitivity: 90 dB
- Maximum power input: 5 mW

## Connectivity

- Microphone: Built-in microphone
- Bluetooth version: 5.0
- Bluetooth profiles: A2DP, Handsfree, HFP, HSP, AVRCP
- Maximum range: 10 m

## Outer Carton

- Length: 37.5 cm
- Number of consumer packagings: 24
- Width: 33.5 cm
- Gross weight: 6.1 kg
- Height: 24.5 cm
- GTIN: 1 69 51613 99399 3
- Nett weight: 2.784 kg
- Tare weight: 3.316 kg

## Inner Carton

- Length: 17.8 cm
- Number of consumer packagings: 3
- Width: 15.8 cm
- Height: 10.4 cm
- Nett weight: 0.348 kg
- Gross weight: 0.67 kg
- Tare weight: 0.322 kg
- GTIN: 2 69 51613 99399 0

## Power

- Battery Type: Lithium-ion
- Talk time: 3+70 hr
- Charging time: 2 hour(s)

## Packaging dimensions

- Height: 15 cm
- Packaging type: Carton
- Type of shelf placement: Both
- Width: 9.5 cm
- Depth: 5 cm
- Number of products included: 1
- EAN: 69 51613 99399 6
- Gross weight: 0.19 kg
- Nett weight: 0.116 kg
- Tare weight: 0.074 kg

## Product dimensions

- Height: 8 cm
- Width: 4.1 cm
- Depth: 3.6 cm

## Accessories

- Included: USB charging cable
- Travel case
- Quick Start Guide
- Ear caps: 3 sizes

## Design

- Color: Black

SHB2515BK/00

# Highlights

## 70 hours play time

Hit the road with multiple charges in your pocket. Head out with a fully powered charging case, and you get up to 70 hours play time. One charge from the case takes around 1.5 hours, and gives you around 3 hours play time or talk time.

## Be free. USB charging case.

Never run out of power. The charging case with built-in 3350 mAH power bank doesn't just charge your headphones--it also charges your phone. Simply plug your smart device into the case via the USB port.

## Comfortable and secure

You can rock your sounds in real comfort thanks to the snug-fitting, lightweight design. The soft rubberized wing tips fit securely under the fold of your outer ear. Interchangeable rubber ear-tip covers let you find the perfect in-ear fit--creating a tight seal so you won't miss a beat.

## Always great sound

The 6 mm neodymium acoustic drivers give you great sound and punchy bass. The oval-shaped acoustic tube maximizes passive noise isolation. Mono mode gives you the option to leave one ear free for when you want to stay aware of the world around you.

## Smart Bluetooth pairing

Your headphones are ready to pair the instant you take them out of the case. Once they're paired, the headphones remember the last device they were paired with.

## Multi-function button.

Easily control music and calls via the multi-function button. Don't like the current track? Skip it with a long press. Want to reject a call and keep listening? A simple button-press takes care of that. The built-in mic with echo cancellation keeps sound clear when you do want to talk.

## Double button-press

A double button-press wakes your phone's voice assistant

## Noise and echo cancellation

No more of those annoying echoes when you are talking on the phone. With our acoustic echo cancellation, you always get a clear, undisturbed connection.

## Ear-tip covers

Ear-tip covers in small, medium, and large--for a perfect fit

## Mono mode

Mono mode for when you want to leave one ear free

## Oval acoustic tube

Oval acoustic tube. Comfort and passive noise isolation

## USB port on charging case

USB port on charging case. Charge your phone on the go



Issue date 2024-03-08

Version: 9.0.5

EAN: 69 51613 99399 6

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)