

Philips
Micro Hi-Fi System

MP3/WMA-CD
USB

MCM700



Obsessed with sound

Relax with great music

Satisfy all your audio needs with the stylish and compact MCM700 micro hi-fi system featuring USB Direct playback. Admire the mirror-finished center unit while you revel in high quality sound delivered from the chic wood-finished speakers.

Unlimited listening pleasure

- Enjoy MP3/WMA music directly from your portable USB drives
- Play MP3/WMA-CD, CD and CD-RW

Enrich your sound experience

- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- Loudness for bass and treble enhancement
- 2x80W RMS/2x160W music power

Design that blends into your interior(s)

- Elegant wood-finished speakers
- High-end component design

PHILIPS

Highlights

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of

the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Loudness

In the sound spectrum, high and low frequencies are relatively less audible to human ears - especially at low volumes. By activating the Loudness feature, the bass and treble will be amplified so you can savor a more balanced sound perception overall.

USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

High-end component design

The component-designed micro system comes with a stand that features four triangular feet. It can prevent any audio frequency distortion due to vibration, overheating and electromagnetic interference generated from the amplifier and CD loader. The result is smooth and excellent sound reproduction.



Specifications

Sound

- Output power: 2 x 80 W RMS, 2 x 160 W music power
- Sound enhancement: loudness, digital sound control 4 modes, Dynamic Bass Boost

Loudspeakers

- Speaker drivers: 4" woofer, Piezo tweeter
- Loudspeaker enhancement: 2-way, speaker grilles detachable
- Speaker types: bass reflex speaker system

Audio playback

- Playback media: WMA-CD, MP3-CD, CD-RW, CD-R, CD
- Disc playback modes: repeat/shuffle/program
- USB Direct playback modes: fast backward/fast forward, play/pause, previous/next, program play, repeat, shuffle, stop

Tuner/Reception/Transmission

- Station presets: 40
- Tuner bands: FM stereo
- Antenna: FM antenna
- RDS: radio text, RDS clock set, station name
- Tuner enhancement: auto digital tuning, auto scan

Connectivity

- Audio/Video output: Headphone (3.5mm)
- Aux in: 2xRCA (Audio)
- USB: USB host

Convenience

- Alarms: CD alarm, radio alarm, USB alarm
- Clock: on main display, sleep timer
- Loader type: motorised, top
- Display enhancements: DIM mode
- Display type: VFD display

Accessories

- Remote control: 24-key with lithium battery
- Others: FM antenna, Quick start guide
- User Manual: multi-languages
- Warranty: World Wide Guarantee booklet

Dimensions

- Gross weight: 10.35 kg
- Main speaker dimensions (W x D): 145 x 215 mm
- Main speaker height: 230 mm
- Main unit depth: 268 mm
- Packaging width: 475 mm
- Main unit height: 156 mm
- Packaging height: 275 mm
- Main unit width: 208 mm
- Packaging depth: 330 mm

Power

- Power supply: 50 Hz
- Power supply: 220 - 240 V

Green

- Eco Power standby: 1 W



Issue date 2014-02-06

Version: 3.0.6

12 NC: 9073 100 13532
EAN: 87 10895 98245 0

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com