

Philips  
Multimedia Speakers 2.1

2.5" Satellite driver

5" Subwoofer  
Headphone out, Audio-in  
70 W, Audio-In

SPA4355



## Dynamic sound

30 W output supported by SPD™ patented bass port technology to give deep, rounded tones. Compatible with any media, this speaker produces rich, full sound with less distortion via its bass reflex system.

### Rich, complex sound

- SPD™ innovative bass port technology for deep, rounded tones
- 30 W RMS total output power
- Bass Reflex Speakers deliver deep and powerful bass
- Well damped driver reduces vibration and sound distortion

### Contemporary design

- Attractive high gloss finish

### Simplicity

- AUX-in and headphone out on wired control
- Compatible with any media

**PHILIPS**

# Specifications

## Product dimensions

- Product dimensions (W x H x D):  
19.5 x 25.3 x 18.5 cm
- Weight: 2,361 kg

## Audio systems

- Frequency range: 20 Hz-20 kHz
- Input impedance: 25 kOhm
- Output power in total: 30 W
- Power: 220 V 50 Hz
- Signal/Noise ratio: >75 dB
- THD: <1%

## Audio systems L/R channels

- Audio power amplifier: Class-AB Amplifier
- Channel separation: >45 dB
- Input sensitivity: 450 mV
- Rated output power: 6 W x 2

## Subwoofer audio systems

- audio power amplifier: Class-AB Amplifier (BTL)
- Input sensitivity: 180mV
- Rated output power: 18W

## Left/Right speakers

- Driver power range: 1-20 W x2
- Frequency range: 100 Hz-18 kHz
- Nominal impedance: 6 ohm

- Sensitivity: 85 dB(2.83 V/1 m)
- Speaker driver: 2.5" full range

## Subwoofer speaker

- Driver power range: 2-60 W
- Frequency range: 55 Hz-250 Hz
- Nominal impedance: 8 ohm
- Sensitivity: 86 dB(2.83 V/1 m)
- Speaker driver: 5"

## Connectivity

- Cable length: 1.3 m
- Connector: 3.5 mm stereo
- Audio input for data: Stereo Audio (3.5 mm jack) 1 x

## Power

- Power LED indicator: Amber

## Convenience

- Remote control: Wired volume control

## Packaging content

- Subwoofer
- 3.5 mm stereo line cable: Fixed
- Quick installation guide
- Remote Control: Wired
- Number of satellites: 2

# Highlights

## SPD™ technology



Philips Sound Purification Duct (SPD) bass port technology delivers the deep, pure tones of the original bass sound. Using an SPD foam material to process the inner surface of the bass pipe, the special acoustic damping invented by Philips reduces noise turbulence and stabilises the tuning frequency. Philips technical and consumer tests confirm this buffer provides less coloured, purer quality bass.

## Well damped driver

A single speaker driver normally incurs a specific frequency division vibration near the edge of the diaphragm, often resulting in some sound distortion. The way to overcome this problem is by using Mylar, a uniform monomer and a much lighter material that is more usually used, around the driver cone. Surrounding the cone in a perfectly symmetrical ring, the resulting damping effect suppresses the asynchronous vibration, resulting in a more balanced and natural sound.

## Bass Reflex Speakers

A chamber behind the speaker driver channels air to the acoustically tuned vents built into the speaker, giving the bass notes a more punchy, realistic sound.

## AUX-in and headphone out

Now you can enjoy your favourite music and entertainment even easier and more conveniently via the aux-in and headphone out jack on wired control. Usually, if you want to connect another device other than your PC, you have to unplug the 3.5 mm jack from the computer and that is not always expedient. But with the aux-in and headphone out connections on front you can quickly and easily listen to music straight from almost any device.



Issue date 2015-03-17

Version: 1.0.4

12 NC: 8670 001 00971  
EAN: 08 71258 16804 97

© 2015 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)