

Philips
Mini Hi-Fi System

MP3

FWM15



MP3-CD Playback

Set your sights on the attractive FWM15 MP3 Mini Hi-Fi System, which delivers superbly rich sound. Plus the freedom to savor 30 hours of your favorite MP3-CD music and intuitive ease-of-use make this set a joy to use!

Enrich your sound experience

- 2x10W RMS/ 2x20W music power
- Full range Bass Reflex Speaker System

Continuous enjoyment of your favorite music

- 3-disc changer for convenient multi-disc playback
- 30 hours of MP3-CD music playback
- Dual Tape Deck

Personalized sound settings

- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound

PHILIPS

Highlights

2x10W RMS/ 2x20W music power 2x10W RMS/ 2x20W music power

Full range Bass Reflex Speaker

Bass Reflex Speakers delivers a deep bass experience. Differ from conventional loudspeakers, the addition of a bass pipe that is acoustically aligned to the woofer optimizes the low frequency roll-off. The result is a deep controlled bass and low distortion. Combined with the response of the woofer, it extends the overall low frequency sounds to create a whole new dimension of deep bass.

3-disc changer

With a three-disc changer for music playback, you can choose between three different CDs inside the device at any one time. This convenient feature allows you to savor a

variety of music while saving you precious time from changing CDs frequently.

30 hours of MP3-CD music

MP3 stands for "MPEG 1 Audio layer-3".MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. MP3 has become the standard audio compression format used on the world wide web, allowing quick and easy audio file transfer.

Dual Tape Deck

Dual Tape Deck

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges

for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Specifications

Sound

- Output Power: 2x20 watts music power
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost 3 steps

Loudspeakers

- Main Speaker: 4" woofer, Bass Reflex Speaker System, Full range

Audio Playback

- Cassette Deck Technology: Mechanical
- Cassette Playback Modes: Continuous Play
- Playback Media: CD, CD-R, CD-RW, MP3-CD
- Disc Playback Modes: 40-Track Programmable, Repeat/one/disk/program, Shuffle Play
- Loader Type: 3 CD Carousel
- Number of decks: 2
- Number of Discs: 3

Audio Recording

- Tape Recording Enhancement: Automatic Recording Level, CD Synchro Start Recording

Tuner/Reception/Transmission

- Auto digital tuning
- Station presets: 40
- Tuner Bands: FM Stereo, MW
- Tuner Enhancements: Auto Store, Easy Set (Plug & Play)

Connectivity

- Headphone: 3.5 mm
- Other connections: FM Antenna, MW Antenna

Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer
- Clock: On main display
- Display Type: FTD
- Eco Power Standby: 1 watt
- Indications: DIM mode

Accessories

- Included accessories: AC Power Cord, FM/MW Antenna, User Manual
- Remote control: 21-key

Dimensions

- Main speaker dimensions (W x H x D): 200 x 310 x 235 mm
- Packaging dimensions (W x H x D): 615 x 414 x 417 mm
- Set dimensions (W x H x D): 265 x 310 x 330 mm
- Weight incl. Packaging: 13 kg

Power

- Power supply: 200-240 V, 50Hz
- Standby power consumption: < 1 W



Issue date 2014-02-05

Version: 3.0.5

12 NC: 9073 100 12134
EAN: 87 10895 85248 7

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com