

Philips
DVD player with USB

DivX

DVP3266



Enjoy DVD and USB video

with DTS Digital Surround

Your dream player with flawless, true-to-life picture quality and the ability to play virtually any disc! The Philips DVD player delivers your movies and music entertainment experience.



Brings audio and video to life

- 192 kHz/24-bit audio DAC enhances analogue sound input
- 5.1 channel audio output for surround sound
- Progressive Scan component video for optimised image quality
- 12-bit/108 MHz video processing for sharp, natural images
- DTS Digital Surround for multi-channel surround sound

Connect and enjoy multiple sources

- Hi-Speed USB 2.0 Link plays media from USB flash drives

Easy to use

- Create MP3s directly from CDs

Plays all your movies and music

- Plays CD, (S) VCD, DVD, DVD+R/RW, DVD-R/RW
- Plays DivX, MP3, WMA and JPEG digital camera photos
- DivX Certified for standard playback of DivX videos

PHILIPS

sense and simplicity

DVD player with USB
DivX

Specifications

Picture/Display

- **D/A converter:** 12-bit, 108 MHz
- **Picture enhancement:** Progressive Scan, Video upsampling

Sound

- **D/A converter:** 24-bit, 192 kHz
- **Frequency response:** 30-20,000 Hz
- **Signal to noise ratio:** >90 dB
- **Distortion and Noise (1 kHz):** >65 dB
- **Crosstalk (1 kHz):** >70 dB
- **Dynamic Range (1 kHz):** >80 dB
- **Sound System:** Dolby Digital

Video Playback

- **Playback Media:** CD, CD-R/CD-RW, Video CD/SVCD, DVD, DivX, DVD+R/+RW, DVD-R/-RW, DVD-Video
- **Compression formats:** MPEG1, MPEG2, DivX 3.11, DivX 4.x, DivX 5.x, DivX 6.0
- **Video disc playback system:** PAL, NTSC

Audio Playback

- **Playback Media:** CD, MP3-CD, MP3-DVD, WMA-CD, CD-R/RW, Audio CD
- **Compression format:** MP3, Dolby Digital, PCM, WMA
- **MP3 bit rates:** 32 - 320 kbps

Still Picture Playback

- **Playback Media:** DVD+R/+RW, DVD-R/-RW, CD-R/RW, Picture CD, Kodak Picture CD

- **Picture compression format:** JPEG
- **Picture enhancement:** Flip photos, Rotate, Zoom, Slideshow

Multimedia Applications

- **Multimedia connections:** USB memory class device
- **Playback Formats:** DivX, JPEG Still pictures, MP3

Connectivity

- **Rear Connections:** Digital coaxial out, Composite video (CVBS) output, ComponentVideo out
- **Progressive, Analogue audio multi-channel out**

Convenience

- **Child Protection:** Child Lock, Parental Control
- **On-Screen Display languages:** English

Power

- **Power supply:** 110-240V, 50/60 Hz
- **Power consumption:** < 10 W
- **Standby power consumption:** < 1 W

Accessories

- **Included Accessories:** Audio/Video cable, 2 x AAA Batteries, Remote Control, World Wide Warranty leaflet, User manual

Dimensions

- **Set dimensions (W x H x D):** 360 x 37 x 210 mm
- **Packaging dimensions (W x H x D):** 415 x 82 x 282 mm

DVP3266/94

Product highlights

192 kHz/24-bit audio DAC

192 kHz sampling enables you to have an accurate representation of the original sound curves. Together with a 24-bit resolution, more information is captured from the original analogue sound wave form, giving a much richer audio reproduction.

5.1 channel audio output

Plays it all

Play virtually any media format you want - whether it is DivX, MP3, WMA or JPEG. Experience the unbeatable convenience of great playability, and the luxury of sharing media files on your TV or home theatre system - in the comfort of your living room.

Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, it writes both fields at the same time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

Create MP3s

Convert the contents of your favourite CDs to MP3 files on your Philips product, and store it directly on a thumbdrive or on your portable media player through a USB cable. Enjoy the convenience of creating MP3 files right in your living room, without a PC, and even while the CD is playing.

DTS Digital Surround

DTS delivers superior surround sound with your DVD movies.



Issue date 2009-02-16

Version: 1.0.7

12 NC: 8670 000 36041
EAN: 87 12581 38710 5

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com