

Philips  
DVD player

DVP3020X



## Turn up your experience

With high quality audio/video

Does size matter? Ever heard of less is more? Introducing the best value DVD player. No complications! Just a simple set that plays practically any disc format, including your digital photos with absolutely no compromise to picture quality.

### Great audio and video performance

- Progressive Scan component video for optimized image quality
- 192kHz/24 bit audio DAC enhances analogue sound input

### Plays it all

- Movies: DVD, DVD+R/RW, DVD-R/RW, (S)VCD
- Music: CD, MP3-CD, CD-R/RW & Windows Media™ Audio
- Photos: Picture CD (JPEG)

### Fits everywhere, goes anywhere

- Compact design
- Ultra-slim design

**PHILIPS**  
sense and simplicity

## Specifications

### Picture/Display

- **Aspect ratio:** 16:9, 4:3
- **D/A converter:** 12 bit, 108 MHz
- **Picture enhancement:** 3/2 - 2/2 motion pull down, Progressive Scan, Video upsampling

### Sound

- **D/A converter:** 24 bit, 192 kHz
- **Frequency response:** 30-20000 Hz
- **Signal to noise ratio:** 90
- **Distortion and Noise (1kHz):** 65 dB
- **Crosstalk (1kHz):** 70 dB
- **Dynamic Range (1kHz):** 80 dB
- **Sound System:** Dolby Digital

### Video Playback

- **Playback Media:** CD, CD-R/CD-RW, Video CD/ SVCD, DVD, DVD-R/-RW, DVD+R/+RW
- **Compression formats:** MPEG1, MPEG2
- **Video disc playback system:** PAL, NTSC

### Audio Playback

- **Playback Media:** CD, MP3-CD, MP3-DVD, WMA-CD, CD-R/RW
- **Compression format:** Dolby Digital, MP3, WMA, PCM
- **MP3 bit rates:** 32 - 256 kbps

### Still Picture Playback

- **Playback Media:** DVD-R/-RW, DVD+R/+RW,

- CD-R/RW, Picture CD, Kodak Picture CD
- **Picture compression format:** JPEG
- **Picture enhancement:** Flip photos, Rotate, Slideshow, Zoom

### Connectivity

- **Rear Connections:** Analog audio Left/Right out, Composite video (CVBS) output, Digital coaxial out, ComponentVideo out Progressive

### Convenience

- **Child Protection:** Parental Control, Child Lock
- **On-Screen Display languages:** English, Hindi

### Power

- **Power supply:** 50/60 Hz, 110-240V
- **Power consumption:** < 10 W
- **Standby power consumption:** < 0.8 W

### Accessories

- **Included Accessories:** 2 x AAA Batteries, Audio/ Video cable, Quick start guide, Remote Control, World Wide Warranty leaflet, User Manual

### Dimensions

- **Set dimensions (W x H x D):** 360 x 37 x 235 mm
- **Packaging dimensions (W x H x D):** 415 x 82 x 320 mm

## Product highlights

### Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

### 192kHz/24 bit audio DAC

192KHz sampling enables you to have an accurate representation of the original sound curves. Together with a 24-bit resolution, more information is captured from the original analogue sound wave form, giving a much richer audio reproduction.

### Multi-format Movies

Multi-format playability allows you to play most disc formats for maximum disc compatibility and viewing pleasure.

### Music: Windows Media™ Audio

Multi-format playability allows you to play most disc formats for maximum disc compatibility and listening pleasure.

### Picture CD (JPEG)

Multi-format playability allows you to view images in the comfort of your living room and play most disc formats for maximum disc compatibility and viewing pleasure.

### Ultra-slim design

The attractive enclosure has a very low profile.



Issue date 2009-02-12

Version: 3.0.7

12 NC: 8622 810 13135  
EAN: 87 10895 93952 2

© 2009 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)