

Philips
Classic micro sound
system

Touch control
200W

MCM355



Obsessed with sound

Relax with great music

Pump up the volume and enjoy your portable music in powerful sound. The Philips classic micro music system features an intuitive touch-control panel, letting you play your music in style. Enjoy MP3/WMA music from USB devices and CDs.

Unlimited listening pleasure

- Play MP3/WMA-CD, CD and CD-RW
- Enjoy MP3/WMA music directly from your portable USB drives

Enrich your sound experience

- 200W RMS total output power
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound

Easy navigation and control

- Touch-control panel for intuitive navigation
- Large display for easy viewing

PHILIPS

Specifications

Sound

- Sound enhancement: digital sound control, Dynamic Bass Boost
- Output power: 200 W RMS

Loudspeakers

- Speaker drivers: 2" tweeter, 5.25" woofer
- Loudspeaker enhancement: 2-way
- Speaker types: bass reflex speaker system

Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD, USB flash drive
- Disc playback modes: fast forward/backward, next/previous track search, repeat/one/all/program, repeat/shuffle/program
- Others: ID3-tag support
- USB Direct playback modes: fast backward/fast forward, play/pause, previous/next, repeat, shuffle, stop

Tuner/Reception/Transmission

- Tuner bands: FM stereo
- RDS: station name, program type, radio text, RDS clock set, news
- Station presets: 20
- Antenna: FM antenna
- Tuner enhancement: auto digital tuning, auto scan, Easy set (plug & play)

Connectivity

- Audio/Video output: Headphone (3.5mm)

- MP3 Link: 3.5mm stereo line in
- USB: USB host

Convenience

- Alarms: CD alarm, radio alarm
- Clock: on main display, sleep timer
- Loader type: motorised, tray
- Display type: VFD display

Accessories

- Cables/Connection: MP3 Link cable, power cord
- Remote control: 32-key with 2xAA batteries
- Others: FM antenna, Quick start guide, User Manual
- Warranty: World Wide Guarantee booklet

Dimensions

- Gross weight: 9.8 kg
- Main speaker height: 257 mm
- Main speaker depth: 240 mm
- Main unit depth: 240 mm
- Packaging width: 675 mm
- Main unit height: 257 mm
- Packaging height: 313 mm
- Main unit width: 173 mm
- Packaging depth: 284 mm

Power

- Power supply: 50/60 Hz
- Power supply: 220 - 240 V

Green

- Eco Power standby: 1 W

Highlights

USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Touch-control panel

Touch-control panel for intuitive navigation



Issue date 2014-02-06

Version: 2.0.9

12 NC: 8670 000 48963
EAN: 87 12581 46039 6

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com