

Philips  
DVD Micro Theater

DivX playback

component design

MCD177



## Turn any room into a theater

plus USB Direct playback

You're in touch with the latest and the coolest - now get a load of the hot 2-in-1 Micro Hi-Fi with DVD, WMA-CD, MP3-CD and USB Direct playback! Relax to your fave movies and music. Home entertainment will never be the same again!

### Enrich your movie experience

- Play DVD, DivX®, (S)VCD, MP3-CD, WMA-CD, CD(RW) & Picture CD
- Dolby Digital for ultimate movie experience
- Progressive Scan component video for optimized image quality

### Enrich your sound experience

- USB Direct for music and photo playback
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- Loudness for bass and treble enhancement
- 800W PMPO/40W RMS total power

### Easy to use

- FM digital tuning with presets
- Wake up and sleep timer functions

### Refined in sound and look

- Elegant wood-finished speakers

**PHILIPS**

sense and simplicity

# Highlights

## USB Direct

Simply plug in your USB device on the system and share your stored digital music and photos with your family and friends.

## Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

## Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

## Loudness

In the sound spectrum, high and low frequencies are relatively less audible to human ears - especially at low volumes. By activating the Loudness feature, the bass and treble will be amplified so you can savor a more balanced sound perception overall.

## Dolby Digital

Because Dolby Digital, the world's leading digital multi-channel audio standards, make use of the way the human ear naturally processes sound, you experience superb quality surround sound audio with realistic spatial cues.

## Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.



# Specifications

## Sound

- Output Power: 2x20W RMS / 800W PMPO
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost, Loudness
- Sound System: Dolby Digital

## Loudspeakers

- Main Speaker: 4" woofer, Bass Reflex Speaker System

## Video Playback

- Playback Media: DVD-Video, Picture CD, Video CD/SVCD, DivX, DVD+R/+RW, DVD-R/-RW
- Disc Playback Modes: A-B Repeat, Angle, PBC, Slow Motion, Zoom, Parental control, Disc Menu, Fast Backward, Fast Forward, OSD
- DVD Region.: 3
- Video Enhancement: Progressive Scan

## Still Picture Playback

- Picture Compression Format: JPEG
- Picture Enhancement: Slideshow with MP3 playback
- Playback Media: CD-R/RW, DVD+R/+RW, Picture CD

## Audio Playback

- Playback Media: WMA-CD, MP3-CD, CD, CD-R, CD-RW
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play, Fast Forward/Backward, Next/Previous Track Search
- Loader Type: Top
- USB Direct Modes: Fast Backward/Fast Forward, Play/Pause, Previous/Next, Program Play, Repeat, Shuffle, Stop

## Tuner/Reception/Transmission

- Auto digital tuning
- Station presets: 20

- Tuner Bands: FM Stereo
- Tuner Enhancements: Auto Store

## Connectivity

- Video Output - Analog: Component Y Pb Pr (cinch), Composite CVBS (yellow cinch), S-Video (on Hosiden)
- Other connections: Digital audio coaxial out, FM Antenna
- Headphone: 3.5 mm
- Audio Connections: 3.5mm Line in, Analogue Audio Out (L/R)
- USB: USB host

## Convenience

- Display Type: LCD
- OSD Languages: English, Traditional Chinese, Portuguese, Spanish
- Alarms: CD Alarm, Radio Alarm, Sleep timer, USB alarm
- Clock: On main display
- Backlight color: Blue

## Accessories

- Included accessories: Composite video cable (Y), FM antenna, World Wide Warranty leaflet
- Remote control: 40-key with Lithium batteries
- User Manual: English, Traditional Chinese
- Quick start guide: English, Traditional Chinese
- AC/DC Adaptor: Switching power supply

## Dimensions

- Set dimensions (W x H x D): 232 x 85 x 275 mm
- Main speaker dimensions (W x H x D): 160 x 250 x 180 mm
- Packaging dimensions (W x H x D): 554 x 405 x 225 mm
- Weight incl. Packaging: 7.3 kg

## Power

- Power supply: 100-240VAC, 50/60Hz



Issue date 2011-07-21

Version: 2.0.9

12 NC: 8670 000 35766  
EAN: 87 12581 38508 8

© 2011 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)