

Philips Classic micro sound system

Dock for iPod/iPhone

DCM186



Obsessed with sound

Relax to great music

Connect to power - and rich sound - when you dock and charge your iPod/iPhone on this Philips Micro system. Dynamic Bass Boost will tantalize your ears while its stylish, compact design will enhance any space and entice your senses.

Enjoy your music from multiple sources

- Play and charge your iPod/iPhone simultaneously
- Play MP3/WMA-CD, CD and CD-RW
- MP3 Link for portable music playback
- Digital tuning with preset stations for extra convenience

Enrich your sound experience

- 15W RMS total output power
- Dynamic Bass Boost for deep and dramatic sound
- Digital Sound Control for optimized music style settings

Easy to use

- Dock any iPod/iPhone, even in its case
- Single remote control for the system and iPod
- · Wake up and sleep timer functions



Specifications

Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Fast Forward/Backward, Next/Previous Track Search, Shuffle Play, Repeat Play
- · Loader Type: Top
- Cradle playback mode: Fast forward and backward, Next and Previous track, Play and Pause, Charging iPhone, Charging iPod

Sound

- Output Power: 15W RMS total power
- Sound Enhancement: Dynamic Bass Boost, Digital Sound Control
- Sound System: Stereo

Loudspeakers

 Main Speaker: 3" woofer, Bass Reflex Speaker System

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Auto digital tuning
- Station presets: 40
- Tuner Enhancements: Auto Store

Connectivity

- Other connections: FM fixed pigtail antenna
- Audio Connections: 3.5mm stereo line in -MP3 link

Convenience

- Alarms: Sleep timer, Radio Alarm, CD Alarm
- · Clock: On main display

- Display Type: LCD
- Backlight color: Blue
- Backlight

Accessories

- Included accessories: World Wide Warranty leaflet
- · Quick start guide: English
- User Manual: English

Dimensions

- Set dimensions (W \times H \times D): 148 \times 233 \times 232 mm
- Main speaker dimensions (W x H x D): 132 x 233 x 159 mm
- Packaging dimensions (W \times H \times D): $370 \times 270 \times 326$ mm
- Weight incl. Packaging: 5.1 kg

Power

Power supply: 220-240V, 50Hz

iPod compatibility

 Compatible with: iPod mini, iPod nano, iPod with color display, iPod 5th Generation, iPod classic, iPod, iPod 1G, iPod 6th Generation, iPod nano 1st Generation, iPod nano 2nd Generation, iPod nano 3rd Generation, iPod nano 4th Generation, iPod nano 5th Generation, iPod touch, iPod touch 2nd Gen 8/16/32GB

iPhone compatibility

Compatible with: iPhone, iPhone 3G, iPhone 3GS, iPhone 4

Highlights

Dynamic Bass Boost



Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottomend bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Dock iPod/iPhone in its case



Smartly designed spring-loaded docking port effortlessly accommodates any iPod or iPhone, without special adaptors. What's more, it works even when most protective cases are on – just dock your iPod or iPhone as it is. Now you can truly have fuss-free enjoyment of your music.

MP3 Link



The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.













Issue date 2014-02-13

Version: 1.1.3

© 2014 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 000 72105 EAN: 87 12581 58274 6

www.philips.com