

Philips  
DVD Mini Hi-Fi System



FWD185

## Enjoy DVD and MP3-CD with dynamic bass

FWD185 is all you need to stay entertained in the comfort of your home. Rely on DBB to deliver deeper and more powerful bass to bring all your favorite movies and music to life. Plus, enjoy photos and music directly from your USB devices.

### Enrich your movie experience

- Play DVD, (S)VCD, MP3-CD, WMA-CD, CD(RW) & Picture CD
- DivX Ultra Certified for enhanced playback of DivX videos
- Dolby Digital for ultimate movie experience
- Progressive Scan component video for optimized image quality

### Enrich your sound experience

- 1800W PMPO / 100W RMS total power
- MAX Sound for instant power boost
- 3-step Dynamic Bass Boost for deep bass experience
- Digital Sound Control for optimized music style settings

### Continuous enjoyment of your favorite music

- USB Direct for music and photo playback
- Karaoke for endless singing entertainment
- Stereo cassette deck
- Digital tuning with 40 preset stations for extra convenience

**PHILIPS**  
sense and simplicity

# Highlights

## Play DVD, MP3, WMA, Picture CD

The Philips player is compatible with most DVD and CD discs available in the market. DVD, (S)VCD, MP3-CD, WMA-CD, CD(RW) and Picture CD - all of them can play on the player. SVCD stands for "Super VideoCD". The quality of a SVCD is much better than a VCD, especially much more sharpen picture than a VCD because of the higher resolution. CD(RW) is a shorthand term for a CD drive that can accept the common rewritable CD format.

## DivX Ultra Certified

With DivX support, you are able to enjoy DivX encoded videos in the comfort of your living room. The DivX media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, and DVD recordable discs. DivX Ultra combines DivX playback with great features like integrated subtitles, multiple audio languages, multiple tracks and menus into one convenient file format.

## Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum

resolution. At such a speed, your eye perceives a sharper picture with no line structure.

## USB Direct

Simply plug in your USB device on the system and share your stored digital music and photos with your family and friends.

## 1800W PMPO / 100W RMS

This system has 1800W PMPO / 100W RMS total output power. RMS refers to Root Mean Square which is a typical measurement of audio power, or rather, the electrical power transferred from an audio amplifier to a loudspeaker, which is measured in watts. The amount of electrical power delivered to the loudspeaker and its sensitivity determines the sound power that is generated. The higher the wattage, the better the sound power emitted by the speaker.

## MAX Sound

MAX Sound technology produces an instant boost in bass, maximizing volume performance and instantly creating the most impressive listening experience with just the touch of a button. Its sophisticated electronic circuitry calibrates existing sound and volume settings, instantly boosting bass and volume to maximum levels without distortion. The end result is a noticeable amplifying of both sound spectrum and volume and a potent audio boost that will add mileage to any music.

## 3-step Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from level one to level three - at the touch of a button! You can customize the bass level that fits your style. Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

## Karaoke

The Karaoke feature on your DVD player provides endless entertainment and maximum audio and singing enjoyment. You can enhance your performance by adding an 'echo' effect to your voice. The key controls allows you to choose the optimal key for your personal vocal range.

## Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.



# Specifications

## Sound

- Total Sound Power (RMS): 100 W
- Output Power: 1800W PMPO
- Sound System: Dolby Digital
- Sound Enhancement: MAX Sound, Dynamic Bass Boost 3 steps, Digital Sound Control

## Loudspeakers

- Main Speaker: 2" tweeter, 5.25" woofer, 2 way, Bass Reflex Speaker System
- Number of Loudspeakers: 2

## Video Playback

- Loader Type: Motorised
- Number of Discs: 1
- Playback Media: DVD, DivX, DivX Ultra, DVD+R/+RW, DVD-R/-RW, SVCD, Video CD, Picture CD
- Video Enhancement: Progressive Scan
- Disc Playback Modes: Disc Menu, OSD, Fast Backward, Fast Forward, Slow Backward, Slow Forward, A-B Repeat, Angle, Zoom, Resume Playback from Stop
- DVD Region.: 3
- USB Direct Playback: JPEG

## Still Picture Playback

- Playback Media: Picture CD, Kodak Picture CD
- Picture Compression Format: JPEG
- Picture Enhancement: Rotate, Slideshow, Zoom, Flip photos

## Audio Playback

- Playback Media: MP3-CD, WMA-CD, CD, CD-R, CD-RW
- Disc Playback Modes: 99-Track Programmable, Repeat/one/all/program
- USB Direct Modes: Play/Pause, Previous/Next, Fast Backward/Fast Forward, Repeat, Stop
- Number of decks: 1
- Cassette Deck Technology: Mechanical
- Cassette Playback Modes: Automatic Stop

## Audio Recording

- Recording Media: Tape
- Tape Recording Enhancement: Automatic Recording Level, CD Synchro Start Recording

## Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW
- Auto digital tuning
- Auto store
- Station presets: 40
- Tuner Enhancements: Easy Set (Plug & Play)

## Connectivity

- Audio Connections: RCA Aux in, Analogue Audio Out (L/R)
- USB: USB host
- Microphone: Dual Microphone sockets
- Headphone: 3.5 mm
- Other connections: ComponentVideo out, Progressive, Composite video (CVBS) out, S-Video out, Digital output (cinch), Subwoofer out, FM Antenna, MW Antenna

## Convenience

- Display Type: VFD display
- Alarms: Sleep timer
- Karaoke: MIC volume, Echo control, Key control
- OSD Languages: English, French, Portuguese, Russian, Spanish, Thai, Traditional Chinese

## Accessories

- Remote control: 45-key
- User Manual: English, Traditional Chinese
- Quick start guide: English, Traditional Chinese
- Standard Package Includes: International Guarantee
- Included accessories: Composite video cable (Y), YPbPr component video cable, Audio Cable, AC Power Cord, FM/MW Antenna

## Dimensions

- Set dimensions (W x H x D): 265 x 310 x 335 mm
- Main speaker dimensions (W x H x D): 222 x 310 x 223 mm
- Packaging dimensions (W x H x D): 570 x 413 x 496 mm
- Weight incl. Packaging: 13.1 kg

## Power

- Power supply: 100-240VAC, 50/60Hz



Issue date 2011-12-13

Version: 4.0.8

12 NC: 8670 000 30349  
EAN: 87 12581 33779 7

© 2011 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)