

Philips docking speaker

- iPhone 5
- iPod nano 7G & iPod touch 5G



AD305

Enjoy music from your iPod/iPhone

Compatible with iPhone 5 and the latest iPods through the Lightning connector, this dashing AD305 docking speaker delivers crystal-clear sound that fills your personal space.

Crystal clear sound

• Bass Reflex Speaker System delivers a powerful, deeper bass

Enjoy your favorite music

- Fast charging and play music via Lightning connector
- · Audio-in for easy portable music playback

Advanced versatility

- Auto clock synchronization with iPod/iPhone when docked
- · LED clock display for clear time viewing

Elegant and compact

• Compact design for any space, any lifestyle



Highlights

Play and charge via Lightning



Enjoy your favorite music while charging your iPod/ iPhone via the new Lightning connector! Just dock it directly on the speaker to play your hand-picked tunes in superb sound. It also charges your device quickly while playing, so you don't have to work about the battery running out.

Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer,

the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

Auto clock synchronization



When connect and dock, this docking system will automatically synchronize the clock with your iPod/iPhone within a few seconds. With this convenient feature, you do not need to set the time manually.

AUDIO-IN (3.5mm)



Make one easy connection and enjoy all your music from portable devices and computers. Simply plug your device to the AUDIO-IN (3.5 mm) port on your Philips set. With computers, the connection is typically made from the headset output. Once linked, you can enjoy your entire music collection directly, on a set of superior speakers. Philips simply delivers better

Specifications

iPhone compatibility

• Compatible with: iPhone 5

iPod compatibility

Compatible with: iPod nano 7th generation, iPod touch 5th generation

Sound

- Sound system: stereo
- Volume control: up/down
- Output power: 4 W RMS

Loudspeakers

Loudspeaker enhancement: bass reflex speaker system

Connectivity

Audio in (3.5mm)

Convenience

- · Charging device: iPod, iPhone
- Clock: Digital, On main display

Power

• Power supply: 100 - 240V AC, 50/60Hz

Dimensions

- Product dimensions (WxDxH): 216 x 102 x 112 mm
- Packaging dimensions (WxDxH): 241 x 136 x 153 mm
- Product weight: 0.68 kg
- Weight incl. Packaging: 1.08 kg





Issue date 2013-06-12

Version: 1.0.6

© 2013 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 001 04322 EAN: 00 60958 52347 72 www.philips.com