



Philips
PhotoFrame

25.9 cm/10.2" LCD

16:9 frame ratio

10FF3CDW



Share your memories

Larger screen for more viewing comfort! Display your digital photos in high pixel density quality, perfect digital color and all the richness of professional prints on the PhotoFrame large screen.

Top quality display for print-like pictures

- High pixel density for sharp and detailed photo display
- imagen Pro for sharp, vibrant and natural skin colors
- Add new glow to old memories with RadiantColor

Easily display and manage your digital photos

- Create albums, slideshows and manage your photos
- An additional SD card slot for unlimited memories
- Have fun with Collage Pro: automatically or edit by yourself
- An easy drag and drop PC software to transfer your photos

Simple intuitive operation and great convenience

- Auto photo orientation to fit portrait or landscape modes
- Power saving via auto dimming by detecting ambient lighting

Classic design: real materials and fine texture

- Real wood front with fine grain - designed for your home

PHILIPS
sense and simplicity

Highlights

Smart Album

Smart Album allows you to create and manage albums, as well as to set up and adjust transition effects to your photo slideshows.

Unlimited memories

Your Philips PhotoFrame comes with an additional SD card slot enabling you to expand the storage space on your PhotoFrame offering plenty of space for all your memories - it's like having virtually unlimited space for your memories and photos! Also thanks to the Philips Memory card manager, you can easily copy and paste images between all your various types of memory cards.

Auto orientation

Automatic landscape/portrait recognition employs a sensor that recognizes PhotoFrame orientation and displays each photo in its proper mode.

Collage Pro

Remember the fun you had working with your photos in the past - such as cutting them and creating nice collections! Collage Pro is a unique and advanced feature provided by Philips digital PhotoFrame. Just like on other Philips digital PhotoFrames with Collage function, you can run collage slideshows automatically (random view). With Collage

Pro, you can also edit and create collages by yourself. You can also easily create a collage even from multiples sources such as an SD card or USB pen drive.

High Pixel Density Display

The very best high density screen shows off your treasured photos with the same 'real life' rich detail and vibrant colors as high quality prints.

imagen Pro for vibrant colors

The unique Philips imagen enhancement technology automatically analyzes your photos to correct color and adjust for optimal contrast. imagen Pro is a more advanced image enhancement which includes the 3 essential elements from imagen to have more color accuracy, color depth and smart contrast. On top of these, imagen Pro offers enhanced skin color, sharper images and flicker-free photo viewing which is very important for still pictures.

PhotoFrame Manager

You can easily connect your Philips PhotoFrame to your computer via a USB cable. The PhotoFrame Manager is a simple to use drag and drop software tool that allows you to simply drag your photos from your computer to your PhotoFrame - it's really that simple!

On top of this, the software enables simple editing like zoom and crop. You can even preview what you have edited before transferring to your PhotoFrame.

RadiantColor

RadiantColor is an exclusive Philips technology for displaying smaller photos in the optimal 4:3 ratio by extending the color on the edges of a less-than-full-screen photo to the sides of the screen, eliminating black bars and aspect ratio distortion.

Real wood with fine grain

There are plenty of digital photo frames in the market with ugly, gadget typ designs. They won't fit my home interior at all. Now, Philips comes with a PhotoFrame with a real wood front with a dark espresso color and fine grain which perfectly fits the simple and clean rear cover design. It not also suits your home decor but brightens up any room!

Smart Power Pro

Smart Power Pro is a sensor that turns PhotoFrame on and off by detecting ambient lighting condition reducing energy consumption for the sake of our environment saving up to one third of your PhotoFrame energy costs. The best news is that this is all done automatically!



Specifications

Picture/Display

- Viewing angle: @ C/R > 10, 120° (H) / 110° (V)
- Lifetime, to 50% brightness: 20000 hr
- Aspect ratio: 16:9
- Panel resolution: 800x480
- Brightness: 250 cd/m²
- Contrast ratio (typical): 300:1

Connectivity

- USB: USB 2.0 Host, USB 2.0 Slave

Storage Media

- Memory Card Types: Compact Flash type I, Secure Digital (SD), Secure Digital (SDHC), Multimedia Card, xD card, Memory Stick, Memory Stick Pro, Memory Stick Duo, Memory Stick Pro Duo
- Built-in memory capacity: 128MB (for 510-1020 photos, around 26MB used by system)
- USB: USB flash drive

Convenience

- Card Reader: Built-in (3x)
- Photo format supported: JPEG photo, Up to 10MB JPEG files, Up to 20 Megapixels
- Placement: Landscape, Photo auto orientation, Portrait
- Buttons and controls: 3 buttons, 4-way navigation key and enter
- Playback mode: Full screen browse, Slideshow, Thumbnail browse
- Album management: Create, Delete, Edit, Rename
- Photo edit: Copy, Delete, Zoom & crop, Rotate
- Photo effects: Black and White, Frames, Sepia, Radiant color
- Slideshow management: Create slideshow, Delete slideshow, Rename slideshow
- Slideshow setting: Collage (multiple pictures), Random, Sequential, Transition effect
- Screen background: Black, Gray, White, Auto-fit
- Setup function: Beep on/off, Brightness adjustment, Clock display enable/disable, Event reminder with snooze, Language, Photo source, Set time and date, Status, Auto on/off, Slideshow
- System status: Firmware version, Remaining memory
- Connected media status: Connected media, Remaining memory
- Plug & Play Compatibility: Mac OS X, Windows 2000/XP or later, Windows Vista
- Regulatory approvals: BSMI, CCC, CE, C-Tick, FCC, GOST, PSB, Switzerland, UL/cUL

- Other convenience: Kensington lock compatible
- On-Screen Display languages: Danish, Dutch, English, French, German, Italian, Russian, Simplified Chinese, Spanish

Accessories

- Included accessories: AC-DC Adapter, Quick start guide, USB cable, CD-ROM with software + manual, Stand

Dimensions

- Temperature range (operation): 0°C to 40°C
- Temperature range (storage): -10°C to 60°C
- Set dimensions with stand (W x H x D): 284.6 x 195.1 x 35.4 mm
- Set dimensions with stand in inch (W x H x D): 11.20 x 7.68 x 1.39 inch
- Set weight (lb): 1.58 lb
- Weight: 0.718 kg

Power

- Power consumption: (System on 5.43 W)
- Power mode supported: AC powered

Outer Carton

- GTIN: 1 06 09585 15362 9
- Number of consumer packagings: 2
- Gross weight: 4.2366 kg
- Outer carton (L x W x H): 36.1 x 26.3 x 25.4 cm
- Nett weight: 2.1376 kg
- Tare weight: 2.099 kg
- Gross weight: 9.340 lb
- Outer carton (L x W x H): 14.2 x 10.4 x 10.0 inch
- Nett weight: 4.713 lb
- Tare weight: 4.627 lb

Packaging dimensions

- UPC: 6 09585 15362 2
- Number of products included: 1
- Packaging type: Carton
- Packaging dimensions (W x H x D): 34 x 24.2 x 10.9 cm
- Gross weight: 1.806 kg
- Nett weight: 1.0688 kg
- Tare weight: 0.7372 kg
- Packaging dimensions (W x H x D): 13.4 x 9.5 x 4.3 inch
- Gross weight: 3.982 lb
- Nett weight: 2.356 lb
- Tare weight: 1.625 lb



Issue date 2013-02-09

Version: 2.1.6

12 NC: 8670 000 39048
UPC: 6 09585 15362 2

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com