



Philips
Micro music system

with Lightning connector
for iPod/iPhone
CD, MP3-CD, USB, FM
20W max



DCM1170

Sound that fits your home

Obsessed with sound

Compatible with the iPhone 5's Lightning connector, this Philips micro sound system delivers great sound as well as a great, stylish design. Sit back and relax, enjoy your music your way, with one simple control.

Enrich your sound experience

- Bass Reflex Speaker System delivers a powerful, deeper bass
- Digital Sound Control for optimized music style settings
- 20W RMS maximum output power

Enjoy your music from multiple sources

- Fast charging and play music via Lightning connector
- USB Direct for easy MP3 music playback
- Play MP3-CD, CD and CD-R/RW
- Audio-in for portable music playback
- Digital tuning with preset stations for extra convenience

PHILIPS

Micro music system
with Lightning connector for iPod/iPhone, CD, MP3-CD, USB, FM, 20W max

Highlights

Play and charge via Lightning



Enjoy your favorite music while charging your iPod/iPhone via the new Lightning connector! Just dock it directly on the speaker to play your hand-picked tunes in superb sound. It also charges your device quickly while playing, so you don't have to work about the battery running out.

Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off

of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

Digital Sound Control



Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

DCM1170/12

Audio-in



The Audio in connectivity allows direct playback of Audio in content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the Audio in is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.

USB Direct for easy MP3 music



Thanks to the complete file transferability, you can easily enjoy the convenience and fun of accessing more digital music via the built-in USB Direct.



Specifications

Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc playback modes: fast forward/backward, next/previous track search, repeat/shuffle/program
- Others: ID3-tag support
- USB Direct playback modes: fast backward/fast forward, play/pause, previous/next, program play, repeat, shuffle, stop
- Docking playback modes: fast forward and backward, next and previous track, play and pause

Sound

- Sound enhancement: digital sound control
- Volume control: up/down
- Maximum output power (RMS): 20W

Loudspeakers

- Speaker types: bass reflex speaker system
- Speaker drivers: 3.5" woofer

Tuner/Reception/Transmission

- Tuner bands: FM stereo
- Station presets: 20
- Tuner enhancement: auto digital tuning

Connectivity

- Audio in (3.5mm)
- USB: USB host

Convenience

- Alarms: CD alarm, radio alarm, iPod alarm, USB alarm
- Loader type: tray
- Charging device: iPhone, iPod

Accessories

- Remote control
- User Manual: multi-languages

Dimensions

- Gross weight: 3.9 kg
- Main speaker dimensions (W x D): 120 x 160 mm
- Main speaker height: 170 mm
- Main unit width: 180 mm
- Main unit height: 177 mm
- Main unit depth: 239 mm
- Packaging width: 231 mm
- Packaging height: 222 mm
- Packaging depth: 556 mm

Power

- Power supply: 110-240V, 50/60Hz

iPod compatibility

- Compatible with: iPod nano 7th generation, iPod touch 5th generation

iPhone compatibility

- Compatible with: iPhone 5



Issue date 2014-06-12

Version: 1.0.8

12 NC: 8670 001 01978
EAN: 87 12581 68400 6

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com