



Philips  
PhotoFrame

20.3cm/8" LCD

4:3 frame ratio

8FF3CME



## Share your memories

How many digital pictures are hidden on your PC? See, share, organize and relive your memories with Philips PhotoFrame™, the easiest way to display your digital photos in stunning quality - without a PC.

### Top quality display for print-like pictures

- 4:3 aspect ratio for optimal distortion-free display
- Add new glow to old memories with RadiantColor
- imagen Pro for sharp, vibrant and natural skin colors

### Easily display and manage your digital photos

- Create albums, slideshows and manage your photos
- Have fun with Collage Pro: automatically or edit by yourself
- An additional SD card slot for unlimited memories
- An easy drag and drop PC software to transfer your photos

### Simple intuitive operation and great convenience

- Auto photo orientation to fit portrait or landscape modes
- Power saving via auto dimming by detecting ambient lighting

### Classic design: real materials and fine texture

- Real brushed aluminium metal front - designed for your home

**PHILIPS**  
sense and simplicity

# Highlights

## 4:3 perfect frame ratio

Philips digital PhotoFrame ensures your photo to be displayed in 4:3 ratio for the best viewing experience.

## RadiantColor

RadiantColor is an exclusive Philips technology for displaying smaller photos in the optimal 4:3 ratio by extending the color on the edges of a less-than-full-screen photo to the sides of the screen, eliminating black bars and aspect ratio distortion.

## Auto orientation

Automatic landscape/portrait recognition employs a sensor that recognizes PhotoFrame orientation and displays each photo in its proper mode.

## Smart Album

Smart Album allows you to create and manage albums, as well as to set up and adjust transition effects to your photo slideshows.

## Collage Pro

Remember the fun you had working with your photos in the past - such as cutting them and creating nice collections! Collage Pro is a unique and advanced feature provided by Philips digital PhotoFrame. Just like on other Philips digital PhotoFrames with Collage

function, you can run collage slideshows automatically (random view). With Collage Pro, you can also edit and create collages by yourself. You can also easily create a collage even from multiples sources such as an SD card or USB pen drive.

## imagen Pro for vibrant colors

The unique Philips imagen enhancement technology automatically analyzes your photos to correct color and adjust for optimal contrast. imagen Pro is a more advanced image enhancement which includes the 3 essential elements from imagen to have more color accuracy, color depth and smart contrast. On top of these, imagen Pro offers enhanced skin color, sharper images and flicker-free photo viewing which is very important for still pictures.

## Brushed aluminium design

There are plenty of digital photo frames in the market with ugly, gadget typ designs. They won't fit my home interior at all. Now, Philips comes with a PhotoFrame with a real brushed aluminium metal front with a fine hair line texture which perfectly fits the simple and clean rear cover design. It not also suits your home decor but brightens up any room!

## Unlimited memories

Your Philips PhotoFrame comes with an additional SD card slot enabling you to expand the storage space on your PhotoFrame offering plenty of space for all your memories - it's like having virtually unlimited space for your memories and photos! Also thanks to the Philips Memory card manager, you can easily copy and paste images between all your various types of memory cards.

## Smart Power Pro

Smart Power Pro is a sensor that turns PhotoFrame on and off by detecting ambient lighting condition reducing energy consumption for the sake of our environment saving up to one third of your PhotoFrame energy costs. The best news is that this is all done automatically!

## PhotoFrame Manager

You can easily connect your Philips PhotoFrame to your computer via a USB cable. The PhotoFrame Manager is a simple to use drag and drop software tool that allows you to simply drag your photos from your computer to your PhotoFrame - it's really that simple! On top of this, the software enables simple editing like zoom and crop. You can even preview what you have edited before transferring to your PhotoFrame.



# Specifications

## Picture/Display

- Viewing angle: @ C/R > 10, 130° (H) / 110° (V)
- Lifetime, to 50% brightness: 20000 hr
- Aspect ratio: 4:3
- Panel resolution: 800 x 600
- Brightness: 250 cd/m<sup>2</sup>
- Contrast ratio (typical): 300:1

## Connectivity

- USB: USB 2.0 Host, USB 2.0 Slave

## Storage Media

- Memory Card Types: Compact Flash type I, Secure Digital (SD), Secure Digital (SDHC), Multimedia Card, xD card, Memory Stick, Memory Stick Pro, Memory Stick Duo, Memory Stick Pro Duo
- USB: USB flash drive
- Built-in memory capacity: 128MB (for 510-1020 photos, around 26MB used by system)

## Convenience

- Card Reader: Built-in (3x)
- Photo format supported: JPEG photo, Up to 10MB JPEG files, Up to 20 Megapixels
- Placement: Landscape, Portrait, Photo auto orientation
- Buttons and controls: 3 buttons, 4-way navigation key and enter
- Playback mode: Full screen browse, Slideshow, Thumbnail browse
- Photo edit: Copy, Delete, Rotate, Zoom & crop
- Photo effects: Black and White, Frames, Radiant color, Sepia
- Slideshow setting: Random, Sequential, Transition effect, Collage (multiple pictures)
- Screen background: Black, White, Gray, Auto-fit
- Setup function: Brightness adjustment, Language, Status, Auto on/off, Beep on/off, Set time and date, Clock display enable/disable, Event reminder with snooze, Photo source, Slideshow
- System status: Firmware version, Remaining memory
- Connected media status: Connected media, Remaining memory
- Plug & Play Compatibility: Windows Vista, Windows 2000/XP or later, Mac OS X
- Regulatory approvals: BSMI, C-Tick, CCC, CE, FCC, GOST, PSB, Switzerland, UL/cUL
- On-Screen Display languages: English, Spanish, German, French, Italian, Dutch, Danish, Russian, Simplified Chinese
- Album management: Create, Delete, Edit, Rename

- Other convenience: Kensington lock compatible
- Slideshow management: Create slideshow, Delete slideshow, Rename slideshow

## Accessories

- Included accessories: AC-DC Adapter, USB cable, Stand, Quick start guide, CD-ROM with software + manual

## Dimensions

- Temperature range (operation): 0°C to 40°C
- Temperature range (storage): -10°C to 60°C
- Set dimensions with stand (W x H x D): 222.6 x 182.2 x 33.2 mm
- Set dimensions with stand in inch (W x H x D): 8.76 x 7.17 x 1.31 inch
- Weight: 0.34 kg
- Set weight (lb): 0.75 lb

## Power

- Power consumption: (System on) 5.09 W
- Power mode supported: AC powered
- Power source: DC output 9V, 2A
- Power supply: 100-240VAC, 50/60Hz

## Outer Carton

- Gross weight: 3.6236 kg
- Outer carton (L x W x H): 29.9 x 24.8 x 24.8 cm
- Nett weight: 1.8576 kg
- Tare weight: 1.766 kg
- Gross weight: 7.989 lb
- Outer carton (L x W x H): 11.8 x 9.8 x 9.8 inch
- Nett weight: 4.095 lb
- Tare weight: 3.893 lb
- GTIN: 1 06 09585 15748 1
- Number of consumer packagings: 2

## Packaging dimensions

- Packaging dimensions (W x H x D): 27.8 x 22.9 x 10.7 cm
- Gross weight: 1.562 kg
- Nett weight: 0.9288 kg
- Tare weight: 0.6332 kg
- Packaging dimensions (W x H x D): 10.9 x 9.0 x 4.2 inch
- Gross weight: 3.444 lb
- Nett weight: 2.048 lb
- Tare weight: 1.396 lb
- Number of products included: 1
- Packaging type: Carton
- UPC: 6 09585 15748 4



Issue date 2013-02-09

Version: 4.0.7

12 NC: 8670 000 41032  
UPC: 6 09585 15748 4

© 2013 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)