

Philips  
docking entertainment  
system



DC146

## Enjoy iPod music in Hi-Fi sound

Play and charge your iPod

Experience your iPod music in superb sound quality with the DC146. Just dock your iPod and enjoy music the way you like it. DC146 also offers fast and precise tuning via its 20 preset stations.

### Enjoy your music from multiple sources

- Play and charge your iPod simultaneously
- Play CD, CD-R and CD-RW

### Enrich your sound experience

- Dynamic Bass Boost for deep and dramatic sound
- 3W RMS total output power

### Easy to use

- Wake up and sleep timer functions
- Digital tuning with 20 preset stations for extra convenience
- Single remote control for the system and iPod

# PHILIPS

# Specifications

## Audio Playback

- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Loader Type: Top
- Cradle playback mode: Charging iPod, Fast forward and backward, Next and Previous track, Play and Pause
- Programmable Tracks: 20

## Sound

- Output Power: 3W RMS
- Volume Control: Volume Control up/down
- Sound Enhancement: Dynamic Bass Boost
- Sound System: Stereo

## Loudspeakers

- Main Speaker: 3" woofer, Bass Reflex Speaker System

## Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW
- Auto digital tuning
- Station presets: 20
- Tuner Enhancements: Auto Store

## Connectivity

- Headphone: 3.5 mm
- Other connections: FM fixed pigtail antenna, AM Antenna
- Audio Connections: 3.5mm Line in

## Convenience

- Alarms: Sleep timer, Radio Alarm, CD Alarm
- Clock: On main display
- Display Type: LCD
- Backlight color: Blue
- Backlight

## Accessories

- Included accessories: FM/MW Antenna, Remote Control, User Manual, World Wide Warranty leaflet, Quick install guide
- Remote control: 24-key remote control
- Cradle: Cradle and adaptors for iPod
- User Manual: English

## Dimensions

- Set dimensions (W x H x D): 148 x 233 x 216 mm
- Main speaker dimensions (W x H x D): 134 x 230 x 152 mm
- Packaging dimensions (W x H x D): 370 x 270 x 326 mm
- Weight incl. Packaging: 5.2 kg

## Power

- Power supply: 220-240V, 50Hz

## iPod compatibility

- Compatible with: iPod, iPod mini, iPod nano, iPod with color display, iPod 5th Generation, iPod classic

# Highlights

## Play and charge your iPod

Enjoy your favorite MP3 music while charging your iPod! The dock lets you connect your iPod directly to the Docking entertainment system so you can listen to your favorite music in superb sound. It also charges your iPod while it plays so you can enjoy your music and not have to worry about your iPod battery running out. Use the remote control to navigate, select and playback the music stored on your iPod. The Docking entertainment system automatically charges your iPod while it is docked.

## Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Issue date 2013-05-10

Version: 5.0.6

12 NC: 8670 000 37139  
EAN: 87 12581 39585 8

© 2013 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)