



Philips  
Clock Radio

AJB4500

## Wake up to DAB or FM radio

Wake up to multiple-source music with the Philips clock radio AJB4500. The built-in interference-free DAB radio brings you more stations in crystal clear sound. Or simply plug and play your portable music via the MP3 Link.

### Enjoy digital quality DAB radio

- Interference-free DAB radio
- FM digital tuning

### Enjoy your music from multiple sources

- MP3 Link for portable music playback

### Easy to use

- Dual alarm time
- Gentle wake for a pleasant waking experience
- Peaceful sleep timer with gradual music fade-out

**PHILIPS**  
sense and simplicity

# Specifications

## Tuner/Reception/Transmission

- DAB: Band III, Info display, Smart Scan, Menu
- Tuner Bands: FM
- Auto digital tuning
- Antenna: FM Antenna
- Station presets: 20

## Connectivity

- Audio output: 3.5 mm jack

## Sound

- Volume Control: Volume Control up/down
- Output power (RMS): 1 W

## Loudspeakers

- Built-in speakers: 1

## Convenience

- Display Type: LCD

- Backlight
- Backlight colour: White

## Power

- Mains power

## Accessories

- Included accessories: User Manual, Quick start guide

## Dimensions

- Packaging dimensions (W x H x D): 219 x 158 x 61 mm
- Product dimensions (W x H x D): 21.9 x 15.8 x 6.1 mm
- Weight: 0.6944 kg
- Weight incl. Packaging: 0.773 kg



# Highlights

## Gentle wake

Start your day the right way by waking up gently to a gradually increasing alarm volume. Normal alarm sounds with a pre-set volume are either too low to wake you up or are so uncomfortably loud that you are rudely jolted awake. Choose to wake up to your favourite music, radio station or buzzer alarm. Gentle wake's alarm volume gradually increases from subtly low to reasonably high in order to gently rouse you.

## Interference-free DAB radio

DAB (Digital Audio Broadcasting) digital radio is, in addition to FM analogue transmission, a new way of broadcasting radio via a network of terrestrial transmitters. It provides listeners with more choices and information delivered in crystal clear, crackle-free sound quality. The technology allows the receiver to lock onto the strongest signal it can find. With DAB digital stations there are no frequencies to remember and sets are tuned by station name, so there is no retuning on the move.

## MP3 Link

The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favourite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player into the audio system.



Issue date 2013-01-10

Version: 2.0.9

12 NC: 8670 000 39676  
EAN: 87 12581 42239 4

© 2013 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)