



Philips
Universal remote control

6in1

SBCRU760

Take full control!

Automatic backlighting, intelligent learning

This universal remote control empowers you with superiority in technology and design.

Single control solution for most devices & brands

- 6-in-1 remote for your TV, DVD, STB, AMP, VCR and CD
- Convenient IR learning from another remote
- Ready for use with Philips equipment

Great convenience

- Eye-catching chrome-plated finish
- The user interface lights up when you pick up the device
- Control multiple devices with a single touch

Easy setup

- Automatically searches for your equipment brand
- Code entry for direct setup of your remote control
- For questions and assistance call our URC service line
- URC support service via dedicated website

PHILIPS

Highlights

Learning functionality

Learning functionality refers to the process through which a remote control captures and stores infrared signals from other remotes for later use. When device codes are not included in the on-board database, they can always be learned from the original remote, simply by pointing to it.

Chrome plated design

Stylish chrome finish that looks good and complements the latest equipment design.

Automatic backlighting

No more searching for buttons in the dark, because when you pick up the remote control, the keys (or LCD display) automatically light up.

One-touch convenience

One-touch control allows you to perform multiple commands with one press of a button via a macro. A macro combines a string of pre-programmed commands under one single button. Therefore, it simply takes one button press to execute a series of functions.

Auto brand search

Getting your new remote control working is simply a case of having your remote automatically search for the most suitable code for your equipment.

Direct code entry

If your remote doesn't automatically find your equipment brand you can always manually key in its digit code from the comprehensive list supplied in the instructions for use.



Specifications

Infrared Capabilities

- Operating distance: 33 ft (10 m)
- Learning IR codes
- Transmitting LEDs: 1
- Universal IR code database
- Number of brands in database: Over 300
- Carrier frequency range: 28 - 70kHz
- Transmission angle: 90 degree
- Learning frequency range: 30 kHz - 60 kHz

Convenience

- Supported devices: TV, VCR, DVD, SAT, CABLE, CD/MD, RECEIVER, AMP
- Backlight
- Backlight color: Red
- Preprogrammed for Philips
- Hands-free autosearch
- Simple system setup
- Copy key function
- Installation steps: 2
- Language support: GB/F/D/NL/E/I
- Languages in manual: GB/F/D/NL/E/I/P/S/FIN/DK/N
- Number of keys: 39
- Regulatory approvals: CE Mark
- Splash proof
- TV functions: Program up/down, Volume up/down,

- mute, Power/standby, Digit keys, AV selection, external, Menu control, Color/Brightness control, Teletext keys, Fast text keys, Previous program, Sleep/timer, 16:9, Guide, info
- SAT/CBL functions: Digit keys, Menu control, Guide, info, Favourites, Text functions
- DVD functions: Transport keys, System menu control, Disc menu control, Digit keys
- VCR functions: Transport keys (6), Showview, VCR plus, Menu control
- Teletext enhancements: Fast text
- Tilt: Tilt sensor

Accessories

- Battery: Yes, 1.5V Battery AA LR6

Dimensions

- Blister dimensions (WxDxH): 160 x 38 x 339 mm
- Carton dimensions (WxDxH): 173 x 121 x 346 mm
- Master carton quantity: 3
- Materials: Recycled PET A

Power

- Battery lifetime: 12
- Battery type: AA / LR6 Alkaline
- Number of batteries: 2



Issue date 2016-10-29

Version: 10.0.11

12 NC: 9082 100 02476
EAN: 87 10895 80308 3

© 2016 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com