



Philips
Portable DVD Player

23 cm/9" LCD
USB

PD9010



Movies that travel with you

with USB for videos, photos and music

Enjoy your movies anytime, anywhere! The portable PD9010 DVD player featuring a 9"/23 cm LCD display lets you indulge in the pleasure of enjoying DVD/MPEG4 movies, MP3-CD/CD music and JPEG photos on the go.

Play your movies, music and photos on the go

- DVD, DVD+/-R, DVD+/-RW, (S)VCD, CD compatible
- MPEG4 playback ensures high-quality compressed video
- MP3-CD, CD and CD-RW playback
- View JPEG images from picture disc

Enrich your AV entertainment experience

- 22.9 cm (9") TFT colour widescreen LCD display
- Built-in stereo speakers

Extra touches for your convenience

- USB connection for video, photo and music playback
- Full Resume on Power Loss
- Car adaptor included

PHILIPS
sense and simplicity

Highlights

MP3-CD, CD and CD-RW playback



MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. A single CD can store up to 10 hours of music.

View JPEG from picture disc



Play JPEG photos that are saved on your disc. Relive your favourite moments with family and friends anytime you want!

DVD, DVD+/-RW, (S)VCD, CD



The Philips Portable DVD player is compatible with most DVD and CD discs available in the market. DVD, DVD+/-R, DVD+/-RW, (S)VCD and CD – all of them can play on the DVD player. DVD+/-R is a shorthand term for a DVD drive that can accept both of the common recordable DVD formats. Likewise, DVD+/-RW handles both common rewritable disc types.

Power Resume

The DVD-Video player remembers where you last stopped watching both if it is powered off directly and if the power supply is discontinued. If you did not change to another disc, your player will resume play where you last stopped the movie just by reloading the disc—making your life a lot easier!

USB connection



Simply plug in your portable USB device to the USB connector on your Philips portable DVD player and playback your digital videos, music or photos directly. Now you can share your favourite moments with family and friends.

MPEG4 playback

MPEG4 is a compression standard allows you to record movies at up to seven to 10 times smaller than the MPEG2 standard without compromising on the picture and sound quality. MPEG4 media can be saved on a CD-Rom, memory card or DVD disc and can be played back in selective DVD players, DVD recorder and Home theatre systems.



Specifications

Picture/Display

- Diagonal screen size: 9 inch / 23 cm
- Resolution: 480(w) x 234(H) x 3(RGB)
- Display screen type: LCD TFT

Video Playback

- Playback Media: DVD, Picture CD, SVCD, Video CD, DVD-R/-RW, MP3-CD, CD-R/CD-RW, DVD+R/+RW, CD
- Disc Playback Modes: Disc Menu, Fast Reverse, Fast Forward, OSD, Repeat, Zoom, Resume Playback from Stop
- Video disc playback system: PAL, NTSC
- Compression formats: MPEG4, XviD

Still Picture Playback

- Picture Compression Format: JPEG digital camera photos

Sound

- Output Power: 250 mW RMS (built-in speakers)
- Output power (RMS): 5 mW RMS (earphone)
- Signal to noise ratio: >80 dB (line out), >76 dB (earphone), >62 dB (built-in speakers)

Audio Playback

- MP3 bit rates: 32 - 320 kbps
- Compression format: Dolby Digital, MP3
- Playback Media: CD, CD-RW, MP3-CD, CD-R
- File systems supported: ISO-9660, Joliet

Connectivity

- Headphone jack: 3.5 mm Stereo Headphone

- AV output: Composite (CVBS) x 1
- USB

Convenience

- Battery charging indication
- Shock proof

Accessories

- AC/DC Adapter: 110-240v, 50/60Hz
- User Manual: English
- Car kit: cigarette outlet adapter, 12vDC

Power

- Battery Type: Built-in battery

Packaging dimensions

- Packaging dimensions (W x H x D): 27.2 x 28.5 x 7 cm
- Net weight: 1.4 kg
- Gross weight: 1.65 kg
- Tare weight: 0.25 kg
- EAN: 87 12581 68129 6
- Number of products included: 1
- Packaging type: Carton
- Type of shelf placement: Laying

Outer Carton

- Outer carton (L x W x H): 28.2 x 23.3 x 30 cm
- Net weight: 4.2 kg
- Gross weight: 5.25 kg
- Tare weight: 1.05 kg
- GTIN: 1 87 12581 68129 3
- Number of consumer packages: 3



Issue date 2013-03-31

Version: 1.0.3

12 NC: 8670 001 01199
EAN: 08 71258 16812 96

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com

* Rechargeable batteries have a limited number of charge cycles and may eventually need to be replaced. Battery life and number of charge cycles vary by use and settings.

* Battery life varies by use and settings.

* Battery life of playtime is approximate and may vary depending on application condition. To optimise battery life, user should turn LCD backlight to minimum, connect to headphones (not built-in speakers) and listen at medium volume level and use the product at room temperature.

* Dolby and the double-D symbol are registered trademarks of Dolby Laboratories Inc.