



Philips
docking entertainment
system

Motorized dock
FM digital tuner



DC177

Enjoy iPod music out loud with slim speakers

The Philips Docking Entertainment System DC177 ensures easy viewing in style with its tilting dock for iPod. Play your MP3 and WMA music via USB Direct and enjoy it all in Hi-Fi sound - delivered through elegant, super-slim speakers.

Enrich your sound experience

- Tilting dock for iPod recharge and music playback
- USB Direct for MP3/WMA music playback
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 2x10W RMS/20W Total Power
- FM digital tuning for station presets

Refined in sound and look

- All-in-one remote control for the system and your iPod
- Super slim speaker design that blends with your interior

PHILIPS

Highlights

USB Direct

With the USB Direct mode, simply plug in your USB device to the USB port on your Philips device and your digital music will be played directly from the Philips device.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically

adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume

settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Specifications

Sound

- Output Power: 2x10W RMS / 20W Total Power
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost, Loudness

Loudspeakers

- Main Speaker: 3.5" woofer

Audio Playback

- Cradle playback mode: Charging iPod, Fast forward and backward, Next and Previous track, Play and Pause
- USB Direct Modes: Fast Backward/Fast Forward, Play/Pause, Previous/Next, Program Play, Repeat, Shuffle, Stop

Tuner/Reception/Transmission

- Auto digital tuning
- Station presets: 20
- Tuner Bands: FM Stereo
- Tuner Enhancements: Auto Store
- Antenna: FM Antenna

Connectivity

- Other connections: FM Antenna
- Headphone: 3.5 mm
- Audio Connections: 3.5mm Line in, Analogue Audio In (L/R)
- USB: USB host

Convenience

- Display Type: LCD

- Alarms: Radio Alarm, Sleep timer, USB alarm
- Clock: On main display
- Backlight
- Backlight color: Blue
- Eco Power Standby: 1 watt

Accessories

- Included accessories: FM antenna, World Wide Warranty leaflet
- Remote control: 40-key with Lithium batteries
- User Manual: English, French, Spanish
- Quick start guide: English, French, Spanish
- AC/DC Adaptor: Switching power supply

Dimensions

- Packaging dimensions (W x H x D): 73.5 x 28.3 x 24.4 mm
- Main speaker dimensions (W x H x D): 140 x 358 x 66 mm
- Set dimensions (W x H x D): 232 x 85 x 275 mm
- Weight incl. Packaging: 6 kg

Power

- Power supply: 100-240VAC, 50/60Hz

iPod compatibility

- Compatible with: iPod 5th Generation, iPod classic, iPod mini, iPod nano 1st Generation, iPod nano 2nd Generation, iPod nano 3rd Generation, iPod touch, iPod with color display



Issue date 2014-02-06

Version: 1.0.5

12 NC: 8670 000 39102
UPC: 6 09585 15368 4

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com