

Philips
CD Soundmachine



AZ2535

Ultimate Gaming Experience

With MAX Sound

Young and vibrant, you demand the ultimate gaming experience! The lean and mean AZ2535 with Philips' Gameport connects you to powerful Max Sound so you can really hear and feel your gaming action and fave music!

Powerful sound you can hear and feel

- MAX Sound for instant power boost
- Bass Reflex Speaker System delivers a powerful, deeper bass

Ready for gaming

- Gameport enables a truly realistic gaming experience
- Sound mode presets to maximize your gaming pleasure

Enjoy favorite music from three different sources

- Compatible with CD-Recordable and CD-ReWritable
- Digital tuning with preset stations for extra convenience
- Autostop cassette deck

PHILIPS

Specifications

Sound

- Equalizer: 3-bands
- Equalizer settings: Gamesound (Blast,Punch,Speed)
- Loudspeaker types: Bass Reflex Speaker System
- Output power (RMS): 2X4W
- Sound Enhancement: MAX Sound, Treble and Bass Control
- Sound System: Stereo
- Speaker diameter: 4"
- Volume Control: Volume Control rotary/encoder

Loudspeakers

- Built-in speakers: 2
- Finishing: Metal
- Loudspeaker Enhancement: Max BASS Port
- Loudspeaker types: Loudspeakers

Audio Playback

- Cassette Deck Technology: Mechanical
- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Loader Type: Top
- Number of decks: 1
- Programmable Tracks: 20

Audio Recording

- Recording Media: Tape
- Tape Recording Enhancement: CD Synchro Start Recording

Tuner/Reception/Transmission

- Antenna: AM Antenna, FM Antenna

- Auto digital tuning
- Tuner Bands: FM, MW

Connectivity

- Audio input for data: Audio Left/Right (RCA) 2x
- Aux in: Gameport
- Headphone: 3.5 mm
- Video input: CVBS Video (RCA) 1x
- Video Output - Analog: Composite CVBS (yellow cinch)

Convenience

- Backlight
- Backlight color: Amber
- Display Digits: 7
- Display Type: LCD

Accessories

- Included accessories: AC Power Cord, Audio/Video cable, User Manual, Warranty certificate

Dimensions

- Packaging dimensions (W x H x D): 560 x 236 x 348 mm
- Product dimensions (W x H x D): 520 x 178 x 287 mm
- Weight: 4.1 kg
- Weight incl. Packaging: 6.1 kg

Power

- Battery type: LR20
- Battery voltage: 1.5 V
- Mains power
- Number of batteries: 8

Highlights

MAX Sound

MAX Sound technology produces an instant boost in bass, maximizing volume performance and instantly creating the most impressive listening experience with just the touch of a button. Its sophisticated electronic circuitry calibrates existing sound and volume settings, instantly boosting bass and volume to maximum levels without distortion. The end result is a noticeable amplifying of both sound spectrum and volume and a potent audio boost that will add mileage to any music.

Bass Reflex Speaker System

Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

Gameport

Gameport is an easy connection solution that links your game console directly to your audio system for enhanced gaming sound quality. Game Sound Mode offers 3 exciting sound settings - Speed mode gets the adrenaline going in high-speed driving and flying games while Punch mode adds power to the punch in hand-to-hand combat games. Finally Blast mode lets you experience the full explosive effects of battle games. A Game Mix function, MIX-IT, available on Mini Hi-Fi Systems, allows game sounds to be mixed with a favorite CD track, radio station or external audio player.

Sound mode presets

Sound mode presets to maximize your gaming pleasure

CD-R/RW Compatible

CD-Rewritable Compatible means that your audio set can play both CD-Recordable (CD-R) and CD-Rewritable (CD-RW) discs. CD-R discs are recordable once and can be played on any audio CD player while CD-RW discs can be recorded and rewritten multiple times and can only be played back on compatible audio CD players. The laser pick-up and CD decoder circuitry of CD-RW compatible players are specially designed to read the special audio CD-RW phase-change recording layer, ensuring you can always play your home-recorded discs on your audio CD system.

Digital tuning with presets

Simply tune into the station that you want to preset, press and hold the preset button to memorize the frequency. With preset radio stations that can be stored, you can quickly access your favorite radio station without having to manually tune the frequencies each time.

Autostop cassette deck

Autostop cassette deck



Issue date 2014-02-05

Version: 3.0.4

12 NC: 9073 101 00942
EAN: 87 10895 79586 9

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com