

Philips
Universal remote control

6-in-I

SRU5060















# Full replacement remote

# Operates more than 1000 brands

A truly excellent universal remote control that gives you complete control over up to six devices from most brands. It has dedicated menu keys and learns codes from your old remote.

# Ideal replacement for your old remote

- 6-in-I remote for your TV, VCR, STB, DVD, CD and AMP.
- · Convenient IR learning from another remote
- · Ready for use with Philips equipment

### **Great convenience**

- · Eye-catching chrome finish
- · Dedicated keys for moving around menus
- A light indicates current active device mode
- · Low battery indication shows when to refresh batteries

#### Quick and easy setup

- · Automatically searches for your equipment brand
- Batteries are included for unwrap-and-zap
- For questions and assistance call our URC service line
- URC support service via dedicated website



#### **Specifications**

#### Convenience

- Universal IR database: TV, VCR, DVD, SAT, CABLE, CD/MD, RECEIVER, AMP
- TV functions: Programme up/down, Volume up/ down, mute, Power/standby, Digit keys, AV selection, external, Menu Control, Colour/ Brightness control, Teletext keys, Fast text keys, Previous programme, Sleep/timer, 16:9, Guide,
- Teletext enhancements: Fast text
- DVD functions: Transport keys, System menu control, Disc menu control, Digit keys
- VCR functions: Transport keys (6), Showview, VCR plus, Menu Control
- SAT/CBL functions: Digit keys, Menu Control, Guide, info, Favourites, Text functions
- Ease of Installation: Autosearch
- Installation steps: 2
- Copy key function
- Language support: GB/F/D/NL/DK/S/N/FIN
- Number of keys: 40
- Pre-programmed for Philips
- Regulatory Approvals: CE Mark
- Splash-proof

#### **Accessories**

• Battery: Yes, I.5 V Battery R03/AAA

#### **Infrared Capabilities**

- Transmitting LEDs: I
- Universal IR code database
- Number of brands in database: Over 1100
- Carrier frequency range: 24-55 kHz
- Transmission angle: 90 degree
- Operating distance: 33 ft (10 m)
- Learning IR codes
- Learning frequency range: 20 kHz to 70 kHz and 455 kHz

#### Power

- Battery lifetime: 12 months
- Number of batteries: 2
- Battery type: AAA

#### **Outer Box**

- Quantity: 6
- EAN/UPC/GTIN: 87 10895 93606 4
- Height: 172 mm
- Length: 312 mm
- Width: 151 mm

#### **Packaging Data**

- 12NC: 908210006487 EAN/UPC/GTIN: 87 10895 93605 7
- Height: 33 mm
- Length: 304 mm
- Width: 157 mm

#### RU5060/86

#### **Product highlights**

#### 6-in-I remote control

Replace a table full of remote controls with one robust unit that'll operate your TV, VCR, satellite receiver, digital or cable set-top box (STB), DVD, CD player and amplifier/receiver regardless of the brand or model.

#### Learning functionality

Learning functionality refers to the process through which a remote control captures and stores infrared signals from other remotes for later use. When device codes are not included in the on-board database, they can always be learned from the original remote, simply by pointing to

#### **Pre-programmed for Philips**

If you have Philips equipment, you can use your universal remote control without programming it because all keys are pre-set for Philips.

#### **Chrome finish**

Stylish chrome finish that looks good and complements the latest equipment design.

#### Dedicated menu keys

Dedicated keys to move easily around your equipment's menus mean simple one finger operation without having to press shift or function shift keys

# Device mode indicator

Small lights keep you informed about which device mode is currently active.

#### Low battery indication

To promptly be aware when the batteries need to be recharged or replaced.

#### Auto brand search

Getting your new remote control working is simply a case of having your remote automatically search for the most suitable code for your equipment.



Issue date 2009-01-22

Version: 1.1.7

© 2009 Koninklijke Philips Electronics N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 9082 100 06487 EAN: 87 10895 93605 7

www.philips.com