



Philips Streamium

Streamium



Access your entire music collection in every room

Access your entire CD collection from the 40 GB hard disk on your wireless music centre and listen in every room. You can listen to different music in every room. Now music can finally follow you wherever you are in your home

Wireless unlimited listening pleasure

- Wireless streaming between music centre and station(s)
- Multiple user access streams to up to 5 stations streaming
- 40 GB hard disk to store and playback up to 750 CDs
- Wireless streaming from PC via UPnP

Easy navigation and control

- 2-way Remote Control for user friendly navigation
- Direct Content Access to artist, album or playlists
- Music Follows Me anywhere, everywhere in the home
- Music Broadcast for simultaneous playback to all Stations

Quality sound performance

- Super Sound Panel with deep bass and clarity

Expandable

- Add 4 additional Wi-Fi Stations

PHILIPS

Technical specifications

Sound

- **Equaliser settings:** Classic, Jazz, Pop, Rock, Techno, Neutral
- **Music power:** (20) W
- **Output power:** 20W + 20W Music Power
- **Sound enhancement:** Dynamic Bass Boost 3 steps, Equaliser, Incredible surround, Treble and bass control, Smart equaliser
- **Type:** Super Sound Panel Speakers
- **Volume Control:** Volume control up / down

Loudspeakers

- **Built-in speakers:** 2
- **Loudspeaker types:** Integrated subwoofer, Super Sound Panel, Non-detachable

Audio Playback

- **Compression format:** MP3, PCM, WMA
- **ID3 tag support**
- **Sample frequencies:** 8-48 kHz (MP3)
- **Hard Disc Playback Mode:** Album, Genre, Playlist, All tracks, Same Artist, Same Genre, Uncompressed tracks
- **Hard Disc Streaming Mode:** Wi-Fi streaming to 5 stations, "My Room, My Music", "Music Follows Me", "Music Broadcast"

Tuner / Reception / Transmission

- Auto digital tuning
- Auto store
- **Number of preset channels:** 40
- **RDS:** News, Program type, Station Information
- **Tuner bands:** FM

Connectivity

- **Antenna:** FM Dipole
- **Aux in:** Line in

- **Headphone:** 3.5 mm
- **Power:** 220 V 50 Hz
- **Wireless connections:** Wireless LAN Adapter 802.11g
- **Wireless Universal Plug & Play:** Enabled
- **Audio cinch in:** Analogue AUX (Centre/Station)

Convenience

- Backlight
- **Backlight colour:** White
- **Display type:** LCD, 128 x 96 dot matrix, 48 mm x 42 mm (Station)
- **Eco power standby:** 1 watt
- Headphone jack
- **On-screen display languages:** Dutch, English, French, German, Italian, Spanish
- **Remote control:** Slim Card
- Signal strength indication
- **Wall mountable / Ceiling Throw:** Wall Mountable

Accessories

- **Batteries:** 1 x Lithium Coin Cell
- **CD-ROM:** Installation CD-ROM
- **Remote control:** card type
- **Warranty card:** Warranty card

Audio Recording

- **Bit rate:** 128, 160 kbps

Dimensions

- **Master carton weight:** 5.1 kg
- **Carton dimensions (WxDxH):** 422mm x 201mm x 349mm
- **Product dimensions (WxDxH):** 360mm x 128mm x 283mm
- **Set weight:** 4.2 kg

Product highlights

Wireless Streaming

With wireless streaming, you don't have to wait to download and store a large file on your audio device before listening to your favourite songs. Instead, the music is sent in a continuous stream and is played as it arrives to up to five music stations at the same time. Your music can now follow you everywhere in your home.

Multiple User Access

Different family members in five different rooms can access & listen to their own choice of music from the Wireless Audio Centre at the same time.

40 GB hard disk/750 CDs

The 40GB hard disc offers a very large capacity for you to store your digital music files. It easily holds up to 750 CDs of your music collection, and the recording speed is so fast that you can basically play and rip a particular song almost at the same time.

2-way Remote Control

With Philips 2-way remote control, you can now navigate through hundreds of songs easily with the one simple press of the remote control. Displaying six lines info listed according to playlist, album, artist, genre or track, this intuitive navigation offers speedy yet simple scrolling through hundreds of files. It allows one handed operation and guarantees a unique user experience.

Direct Content Access

No more searching through hundreds of your CDs to find your favourite track by a particular artist. With the intuitive User Interface built-in the Philips Wireless Audio Centre, you can now have almost instantaneous and direct access to your stored digital music collection on the hard disc (up to 750 CDs) and go straight to the music you want to listen to, listed by Artist, Album, Playlist, Genre or Tracks.

Music Broadcast - Party mode!

Be your own DJ at your home party and simultaneously broadcast your favourite dance music from the Wireless Music Centre to all Wireless Music Stations installed in various parts of your home. Great for parties!

Music Follows Me between rooms

Music follows Me feature allows you to bring your favourite music from room to room in your house without having to restart navigation and playback of that particular track. By simply pressing a button, your favourite song will follow you anywhere you go in your house.

* Windows logo are trademarks, or registered trademarks of Microsoft Corporation in the United States and/or other countries.



Date of issue 2006-10-06

Version: 7.0

12 NC: 9073 100 12643
EAN: 87 10895 88450 1

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.
© 2006 Koninklijke Philips Electronics N.V.
All Rights reserved.
www.philips.com

