



Philips
PhotoFrame

20.3 cm/8" LCD

4:3 frame ratio

8FF3CME



Share your memories

How many digital pictures are hidden on your PC? See, share, organise and relive your memories with Philips PhotoFrame™, the easiest way to display your digital photos in stunning quality - without a PC.

Top-quality display for print-like pictures

- 4:3 aspect ratio for optimal distortion-free display
- Add new glow to old memories with RadiantColor
- imagen Pro for sharp, vibrant and natural skin colours

Easily display and manage your digital photos

- Create albums and slideshows and manage your photos
- Have fun with Collage Pro: automatically or edit things yourself
- An additional SD card slot for unlimited memories
- Easy drag and drop PC software to transfer your photos

Simple intuitive operation and great convenience

- Auto photo orientation to fit portrait or landscape modes
- Power saving via auto dimming, by detecting ambient lighting

Classic design: real materials and fine texture

- Real brushed aluminium metal front - designed for your home

PHILIPS
sense and simplicity

Highlights

4:3 perfect frame ratio

Philips digital PhotoFrame ensures your photo is displayed in 4:3 ratio for the best viewing experience.

RadiantColor

RadiantColor is an exclusive Philips technology for displaying smaller photos in the optimal 4:3 ratio by extending the colour on the edges of a less-than-full-screen photo to the sides of the screen, eliminating black bars and aspect ratio distortion.

Auto orientation

Automatic landscape/portrait recognition employs a sensor that recognises PhotoFrame orientation and displays each photo in its proper mode.

Smart Album

Smart Album allows you to create and manage albums, as well as set up and adjust transition effects for your photo slideshows.

Collage Pro

Remember the fun you had working with your photos in the past - such as cutting them and creating nice collections! Collage Pro is a unique and advanced feature provided by Philips digital PhotoFrame. Just like on other Philips digital PhotoFrames with Collage

function, you can run collage slideshows automatically (random view). With Collage Pro, you can also edit and create collages yourself. You can also easily create a collage from multiples sources such as an SD card or USB pen drive.

imagen Pro for vibrant colours

The unique Philips imagen enhancement technology automatically analyses your photos to correct colour and adjust for optimal contrast. imagen Pro is a more advanced image enhancement which includes the 3 essential elements from imagen to have more colour accuracy, colour depth and smart contrast. On top of these, imagen Pro offers enhanced skin colour, sharper images and flicker-free photo viewing which is very important for still pictures.

Brushed aluminium design

There are plenty of digital photo frames in the market with ugly, gadget-type designs. They won't fit my home interior at all. Now, Philips comes with a PhotoFrame with a real brushed aluminium metal front with a fine hair-line texture which perfectly fits the simple and clean rear cover design. It not only suits your home decor but brightens up any room!

Unlimited memories

Your Philips PhotoFrame comes with an additional SD card slot enabling you to expand the storage space on your PhotoFrame offering plenty of space for all your memories - it's like having virtually unlimited space for your memories and photos! Also thanks to the Philips Memory card manager, you can easily copy and paste images between all your various types of memory cards.

Smart Power Pro

Smart Power Pro is a sensor that turns PhotoFrame on and off by detecting ambient lighting condition. This reduces energy consumption for the sake of our environment saving up to one third of your PhotoFrame energy costs. The best news is that this is all done automatically!

PhotoFrame Manager

You can easily connect your Philips PhotoFrame to your computer via a USB cable. The PhotoFrame Manager is a simple to use drag and drop software tool that allows you to simply drag your photos from your computer to your PhotoFrame - it's really that simple! On top of this, the software enables simple editing like zoom and crop. You can even preview what you have edited before transferring to your PhotoFrame.



Specifications

Picture/Display

- Viewing angle: @ C/R > 10, 130° (H)/110° (V)
- Lifetime, to 50% brightness: 20,000 hr
- Aspect ratio: 4:3
- Panel resolution: 800 x 600
- Brightness: 250 cd/m²
- Contrast ratio (typical): 300:1

Connectivity

- USB: USB 2.0 Host, USB 2.0 Slave

Storage Media

- Memory Card Types: Compact Flash type I, Secure Digital (SD), Secure Digital (SDHC), Multimedia Card, xD card, Memory Stick, Memory Stick Pro, Memory Stick Duo, Memory Stick Pro Duo
- USB: USB flash drive
- Built-in memory capacity: 128 MB (for 510-1020 photos, around 26 MB used by system)

Convenience

- Card Reader: Built-in (3 x)
- Photo format supported: JPEG photo, Up to 10 MB JPEG files, Up to 20 Megapixels
- Placement: Landscape, Portrait, Photo auto orientation
- Buttons and controls: 3 buttons, 4-way navigation key and enter
- Playback mode: Full screen browse, Slideshow, Thumbnail browse
- Photo edit: Copy, Delete, Rotate, Zoom and crop
- Photo effects: Black and White, Frames, Radiant colour, Sepia
- Slideshow setting: Random, Sequential, Transition effect, Collage (multiple pictures)
- Screen background: Black, White, Grey, Auto-fit
- Setup function: Brightness adjustment, Language, Status, Auto on/off, Beep on/off, Set time and date, Clock display enable/disable, Event reminder with snooze, Photo source, Slideshow
- System status: Firmware version, Remaining memory
- Connected media status: Connected media, Remaining memory
- Plug and Play Compatibility: Windows Vista, Windows 2000/XP or later, Mac OS X

- Regulatory approvals: BSMI, C-Tick, CCC, CE, FCC, GOST, PSB, Switzerland, UL/cUL
- On-Screen Display languages: English, Spanish, German, French, Italian, Dutch, Danish, Russian, Simplified Chinese
- Album management: Create, Delete, Edit, Rename
- Other convenience: Kensington lock compatible
- Slideshow management: Create slideshow, Delete slideshow, Rename slideshow

Accessories

- Included accessories: AC-DC Adapter, USB cable, Stand, Quick start guide, CD-ROM with software + manual

Dimensions

- Weight: 0.34 kg
- Temperature range (operation): 0°C to 40°C
- Temperature range (storage): -10°C to 60°C
- Set dimensions with stand (W x H x D): 222.6 x 182.2 x 33.2 mm

Power

- Power consumption: (System on) 5.09 W
- Power mode supported: AC powered
- Power source: DC output 9 V, 2 A
- Power supply: 100-240 VAC, 50/60 Hz

Outer Carton

- Gross weight: 3.5528 kg
- Outer carton (L x W x H): 29.9 x 24.8 x 24.8 cm
- Net weight: 1.7868 kg
- Tare weight: 1.766 kg
- GTIN: 1 87 12581 43294 9
- Number of consumer packages: 2

Packaging dimensions

- Packaging dimensions (W x H x D): 27.8 x 22.9 x 10.7 cm
- Gross weight: 1.526 kg
- Net weight: 0.8934 kg
- Tare weight: 0.6326 kg
- EAN: 87 12581 43294 2
- Number of products included: 1
- Packaging type: Carton



Issue date 2012-05-11

Version: 4.0.8

12 NC: 8670 000 41031
EAN: 87 12581 43294 2

© 2012 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com