

Philips
Portable DVD Player with
Zero Bright Dot™ screen

25.9 cm (10.2") widescreen LCD



PET1031



Swivel Screen, flexible view

Up to 5-hour playback

Enjoy movies on the Philips PET1031 Portable DVD Player with 10.2" LCD display and a 180-degree swivel screen. Plus, share your favorite video experiences with pals thanks to SD card slot and USB2.0 connector. Comes with car mount kit.

Immerse in AV entertainment on the go

- Play DVD, DVD+/-R and DVD+/-RW, (S)VCD, DivX® & MPEG4 movies
- DivX Ultra for enhanced playback of DivX media files
- Play MP3/WMA-CD, CD and CD-RW
- Share JPEG image files with Picture CD

Perfect viewing anywhere

- Zero Bright Dot™ screen for optimal screen quality
- High-resolution 10.2" TFT LCD display for great viewing
- Enjoy movies in 16:9 widescreen format
- Built-in quality stereo speakers

For ultimate convenience

- Enjoy up to 5 hours continuous non-stop playback*
- 180-degree swivel screen for improved viewing flexibility
- USB 2.0 connector and SD memory card slot
- Smart Car Mount for ease-of-use

PHILIPS
sense and simplicity

Highlights

Play DVD, DivX and MPEG4

With DivX® support, you are able to enjoy DivX® encoded videos in the comfort of your living room. The DivX® media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, memory cards and DVD-video. DivX® CDs can be played back on selected DVD players, DVD Recorders and Home Theater Systems.

Share picture CD (JPEG)

Multi-format playability allows you to view images on the go and play most disc formats for maximum disc compatibility and viewing pleasure.

Zero Bright Dot™ screen

Enjoy highest-quality images that are free from annoying blank spots on the LCD screen. LCD displays commonly have imperfections, termed as 'bright dots' by the LCD industry. A limited number of bright dots were once considered an inevitable side effect of LCD mass production. With Philips' strict quality control procedures used in our Portable DVD Players, our LCD displays are produced with zero tolerance for bright dots. Select Portable DVD Players come with Philips Zero Bright Dot™ Policy to guarantee optimal screen quality.


USB 2.0 and SD card slot

Enjoy the high-speed and convenience of accessing more capacity to transfer photos,

videos and MP3 music files by using USB 2.0. You can also access more capacity to store photos, videos and MP3 music files on your Philips player by inserting an SD card into the built-in SD card slot.

Smart Car Mount

To enjoy entertainment on the go, why not bring your portable DVD player from home on the road with you? A unique Car Mount system ensures ease-of-use, with a quick-release arm that facilitates easy removal of the player when not in use. You can bring the portable DVD player with you, leaving just the Mount behind in the car.



Specifications

Picture/Display

- Display screen type: LCD TFT
- LCD panel type: Anti-glare polarizer
- Diagonal screen size (inch): 10.2 inch
- Resolution: 800(W)×480(H)×3(RGB)
- Brightness: 200 cd/m²
- Contrast ratio (typical): 250:1
- Effective viewing area: 222.0×133.2mm
- Pixel pitch: 0.1905(W)×0.1905(H) mm
- Response time (typical): 30 ms

Sound

- Output Power: 250mW RMS(built-in speakers)
- Output power (RMS): 10mW RMS(earphone)
- Signal to noise ratio: >80dB(line out), >76dB(earphone), >62dB(built-in speakers)

Video Playback

- Playback Media: DVD, DVD+R/+RW, DVD-R/-RW, SVCD, Video CD, CD, CD-R/CD-RW, MP3-CD, WMA, Picture CD
- Disc Playback Modes: OSD, A-B Repeat, Angle, Disc Menu, Fast Backward, Fast Forward, Repeat, Shuffle Play, Slow Backward, Slow Forward, Zoom
- Video disc playback system: NTSC, PAL
- Compression formats: Divx, MPEG4

Audio Playback

- Compression format: Dolby Digital, MP3, WMA
- Playback Media: CD, MP3-CD, CD-R, CD-RW, WMA-CD
- File systems supported: ISO-9660, Joliet
- MP3 bit rates: 32 - 320 kbps
- WMA bit rates: 32 - 192 kbps

Connectivity

- DC in: 9~12V

- AV output: Composite (CVBS) x1
- Headphone jack: 3.5mm Stereo Headphone
- SD/MMC card slot
- USB
- Other connections: Component Video out Interlaced, S-Video out

Convenience

- Shock proof
- Battery charging indication

Accessories

- AC/DC Adaptor: DC-in 9~12V; 110-240v, 50/60Hz
- Car kit: cigarette outlet adaptor, 12vDC
- Remote control: AY5507 slim remote
- Cables: A/V cable x1, S-video cable x1, Component cable x 1
- User Manual: English
- Included accessories: S-video cable, Component Video cable
- Smart car mount: 1 set

Power

- Battery Type: Built-in battery

Dimensions

- Master carton dimensions: 350 x 305 x 460 mm
- Master carton quantity: 3
- Master carton weight: 9 kg
- Packaging type: D-box
- Packaging dimensions (W x H x D): 336 x 282 x 145 mm
- Product dimensions (W x H x D): 270 x 32 x 188 mm
- Product weight: 1.3 kg



Issue date 2013-02-01

Version: 1.0.2

12 NC: 8670 000 38265
EAN: 87 12581 40535 9

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com