



Philips  
PC Camera

**CIF**  
CMOS

**SPC300NC**

# Simply superior performance!

## Live video messaging

If you want to get into the fascinating world of face-to-face video chatting and video mails, the SPC 300NC is the smart way to get on-line and share the live action. It comes with everything you need, including v-mail software.

### High picture & video quality

- 30 frames per second video
- VGA snapshot resolution (640x480) for sharp images

### Face-to-face video chatting

- Go face-to-face with free instant messaging services
- External microphone for optimum positioning

### Easy to use

- V(ideo)Launch software
- Get started in a second with VLounge with QuickLaunch button
- Snapshot button for instant photos
- Rotating lens for perfect aiming and natural images

**PHILIPS**  
sense and simplicity

## Specifications

### Video & snapshot capturing

- **Sensor:** CMOS
- **Sensor resolution:** QVGA
- **Video resolution:** QVGA
- **Snapshot resolution:** QVGA
- **Interpolated snapshot res.:** VGA
- **Max. frame rate:** 30 fps
- **Lens:** f: 6 mm, F2.8, D42°
- **White balance:** 2600 – 7600 k
- **Min. illuminance:** < 10 lux
- **Colour depth:** 24 bit

### Mechanics

- **Laptop clamp:** No
- **LCD clamp:** No
- **CRT stand:** No
- **Desktop stand:**
- **Digital built-in microphone:** No
- **Quicklaunch button:**
- **Snapshot button:**

### Accessories

- **Included Accessories:** Quick install guide, User

Manual, External microphone

### Software

- **VLounge:** Basic
- **Add video to:** MSN Messenger, Yahoo! Messenger, AOL Messenger

### System Requirements

- **Operating System:** Microsoft Windows 98, Microsoft Windows ME, Microsoft Windows 2000, Microsoft Windows XP
- **Processor:** Pentium II 500MHz or faster
- **RAM memory:** 128 MB RAM
- **Sound card:**
- **USB:** Free USB port
- **Internet connection:**
- **Hard disk space:** 200 MB
- **CD-ROM or DVD-ROM Drive:**

### Connectivity

- **PC Link:** USB 1.1

## Product highlights

### 30 frames per second video

With a 30 frames per second refresh rate you will enjoy natural-looking and full motion video calls without jumpy images some webcams produce.

### VGA snapshot resolution

The VGA resolution of your snapshots ensures sharp images for use in documents, webpages and e-mails.

### Works with all IM services

Add video to Yahoo!, MSN and AOL Messenger. This PC Camera also works with Windows Messenger and NetMeeting.

### External microphone included

With a separate external microphone, you have the freedom to place it where it best picks up your voice for relaxed on-line video chatting.

### VLounge software

Software for capturing, managing and archiving snapshots and video clips in a very convenient way. With just a couple of mouse clicks you will be able to create and send Video mails. This software package provides all you need to take full advantage of your Philips PC Camera.

### VLounge QuickLaunch button

To start up VLounge simply press the QuickLaunch button

### Snapshot button

With just one press of this button, your webcam takes a picture automatically - ready for adding to e-mails, web pages or documents.

### Rotating lens

Rotating lens for perfect aiming and natural images. You can get the right camera angle quickly and easily without having to put things underneath it to change the tilt.

